

HITACHI

SM0174

RAK25NH4 RAC25NH4 RAK35NH4 RAC35NH4 RAK50NH4 RAC50NH4


SERVICE MANUAL TECHNICAL INFORMATION

REFER TO THE FOUNDATION MANUAL


FOR SERVICE PERSONNEL ONLY

CONTENTS

SPECIFICATIONS	5
CONSTRUCTION AND DIMENSIONAL DIAGRAM	6
MAIN PARTS COMPONENT	8
WIRING DIAGRAM	10
CIRCUIT DIAGRAM	12
PRINTED WIRING BOARD LOCATION DIAGRAM	18
BLOCK DIAGRAM	20
BASIC MODE	22
REFRIGERATING CYCLE DIAGRAM	35
AUTO SWING FUNCTION	37
DESCRIPTION OF MAIN CIRCUIT OPERATION	38
SERVICE CALL Q & A	69
TROUBLE SHOOTING	72
PARTS LIST AND DIAGRAM	92



RAK-25NH4
RAK-35NH4
RAK-50NH4



RAC-25NH4
RAC-35NH4
RAC-50NH4

SPECIFICATIONS

TYPE		DC INVERTER (WALL TYPE)							
		INDOOR UNIT		OUTDOOR UNIT		INDOOR UNIT		OUTDOOR UNIT	
MODEL		RAK-25NH4	RAC-25NH4	RAK-35NH4	RAC-35NH4	RAK-50NH4	RAC-50NH4		
POWER SOURCE		1 PHASE, 50 Hz, 220-230V			1 PHASE, 50 Hz, 220-230V		1 PHASE, 50 Hz, 220-230V		
COOLING	TOTAL INPUT (W)	695 (155~1,050)		1,080 (155~1,280)		1,780 (155~2,200)			
	TOTAL AMPERES (A)	3.20-3.05		4.94-4.72		8.17-7.82			
	CAPACITY	(kW)	2.50 (0.90 ~ 3.00)		3.50 (0.90 ~ 4.00)		5.00 (0.90 ~ 5.20)		
(B.T.U./h)		8,540		11,950		17,070			
HEATING	TOTAL INPUT (W)	900 (115 ~ 1,400)		1,320 (115 ~ 1,920)		1,970 (115 ~ 2,100)			
	TOTAL AMPERES (A)	4.15-4.00		6.04-5.77		9.04-8.65			
	CAPACITY	(kW)	3.50 (0.90 ~ 5.00)		4.80 (0.90 ~ 6.60)		6.50 (0.90 ~ 8.10)		
(B.T.U./h)		11,950		16,390		22,200			
DIMENSIONS (mm)	W	860	750	860	750	860	850		
	H	285	570	285	570	285	650		
	D	183	280	183	280	183	298		
NET WEIGHT (kg)		9.0	38	9.0	38	9.0	60		

※ After installation

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

ROOM AIR CONDITIONER INDOOR UNIT + OUTDOOR UNIT

MAY 2003

Refrigeration & Air-Conditioning Division

FOR SERVICE PERSONNEL ONLY

HITACHI
Inspire the Next

SPLIT UNIT AIR CONDITIONER INSTALLATION MANUAL

Outdoor Unit



RAC-25NH4
RAC-35NH4
RAC-50NH4

- Carefully read through the procedures of proper installation before starting installation work.
- The sales agent should inform customers regarding the correct operation of installation.

Tools Needed For Installation Work

- ⊕ ⊖ Screwdriver
- Measuring Tape
- Knife
- Saw
- ø 65mm Power Drill
- Hexagonal Wrench Key (⊠ 4mm)
- Wrench (14, 17, 22, 26, 27mm)
- Gas Leakage Detector
- Pipe Cutter
- Putty
- Vinyl Tape
- Pliers
- Flare Tool

SAFETY PRECAUTION

- Read the safety precautions carefully before operating the unit.
- The contents of this section are vital to ensure safety. Please pay special attention to the following sign.

WARNING Incorrect methods of installation may cause death or serious injury.

CAUTION Improper installation may result in serious consequence.

Be sure that the unit operates in proper condition after installation. Explain to customer the proper way of operating the unit as described in the user's guide.

WARNING

- Please request your sales agent or qualified technician to install your unit. Water leakage, short circuit or fire may occur if you do the installation work yourself.
- Please observe the instructions stated in the installation manual during the process of installation. Improper installation may cause water leakage, electric shock and fire.
- Make sure that the units are mounted at locations which are able to provide full support to the weight of the units. If not, the units may collapse and impose danger.
- Observe the rules and regulations of the electrical installation and the methods described in the installation manual when dealing with the electrical work. Use power cables approved by the authorities of your country.
- Be sure to use the specified wire for connecting the indoor and outdoor units. Please ensure that the connections are tight after the conductors of the wire are inserted into the terminals. Improper insertion and loose contact may cause over-heating and fire.
- Please use the specified components for installation work. Otherwise, the units may collapse or water leakage, electric shock and fire may occur.
- Be sure to use the specified piping set for R-410A. Otherwise, this may result in broken copper pipes or faults.
- When installing or removing an air conditioner, only specified refrigerant (R410A) shall be allowed, do not allow air or moisture to remain in the refrigeration cycle. Otherwise, pressure in the refrigeration cycle may become abnormally high so that a rupture may be caused.
- Be sure to ventilate fully if a refrigerant gas leak while at work. If the refrigerant gas comes into contact with fire, a poisonous gas may occur.
- After completion of installation work, check to make sure that there is no refrigeration gas leakage. If the refrigerant gas leaks into the room, coming into contact with fire in the fan-driven heater, space heater, etc., a poisonous gas may occur.
- Unauthorized modifications to the air conditioner may be dangerous. If a breakdown occurs please call a qualified air conditioner technician or electrician. Improper repairs may result in water leakage, electric shock and fire, etc.

CAUTION

- A circuit breaker or fuse (16A time delay) must be installed. Without a circuit breaker or fuse the danger of electric shock exists. A main switch with a contact gap of more than 3mm has to be installed in the power supply line to the outdoor unit.
- Do not install the unit near a location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it.
- Please ensure smooth flow of water when installing the drain hose.
- Piping shall be suitable supported with a maximum spacing of 1m between the supports.



THE CHOICE OF MOUNTING SITE (Please note the following matters and obtain permission from customer before installation).

OUTDOOR UNIT

⚠ WARNING



- The Outdoor unit must be mounted at a location which can support heavy weight. Otherwise, noise and vibration will increase.

⚠ CAUTION

- Do not expose the unit under direct sunshine or rain. Besides, ventilation must be good and clear of obstruction.
- The air blown out of the unit should not point directly to animals or plants.
- The clearances of the unit from top, left, right and front are specified in figure below. At least 3 of the above sides must be open air.
- Be sure that the hot air blown out of the unit and noise do not disturb the neighbourhood.
- Do not install at a location where there is flammable gas, steam, oil and smoke.
- The location must be convenient for water drainage.
- Place the Outdoor unit and its connecting cord at least 1m away from the antenna or signal line of television, radio or telephone. This is to avoid noise interference.

Names of Outdoor Components

No.	Item	Qty
⑩	Bush (RAC-25NH4, RAC-35NH4)	2
	(RAC-50NH4)	3
⑪	Drain Pipe	1
⑬	Bush	1



- Please mount the Outdoor unit on stable ground to prevent vibration and increase of noise level.
- Decide the location for piping after sorting out the different types of pipe available.
- When removing side cover, please pull the handle after undoing the hook by pulling it downward.






Figure showing the Installation of Outdoor Unit.



CONDENSED WATER DISPOSAL OF OUTDOOR UNIT

- There are holes on the base of Outdoor unit for condensed water to exhaust.
- In order to flow condensed water to the drain, the unit is installed on a stand or a block so that the unit is 100mm above the ground as shown figure. Join the drain pipe to one hole.
- At first insert one portion of the hook to the base (Portion A), then pull the drain pipe in the direction shown by the arrow while inserting the hook into the base. After installation, check whether the drain pipe cling to the base firmly.




When Using and Installing In Cold Areas

When the air conditioner is used in low temperature and in snowy conditions, water from the heat exchanger may freeze on the base surface to cause poor drainage. When using the air conditioner in such areas, do not install the bushings. Keep a minimum of 250mm between the drain hole and the ground. When using the drain pipe, consult your sales agent.

※ For more details, refer to the installation Manual for Cold Areas.

1 Preparation of Pipe

- Use a pipe cutter to cut the copper pipe.



CAUTION

- Jagged edge will cause leakage.
- Point the side to be trimmed downwards during trimming to prevent copper chips from entering the pipe.

- Before flaring, please put on the flare nut.




- Recommend to use R410A flaring tool.

Outer Diameter (mm)	A (mm)	
	For R410A tool	For R22 tool
6.35	0.0 ~ 0.5mm	1.0mm
9.52	0.0 ~ 0.5mm	1.0mm
12.7	0.0 ~ 0.5mm	1.0mm

2 Pipe Connection

CAUTION In case of removing flare nut of an Indoor unit, first remove a nut of small diameter side, or a seal cap of big diameter side will fly out. Prevent water from entering into the piping when working.




	Outer dia. of pipe	Torque N-m (kgf · cm)
Small dia. side	6.35 (1/4")	13.7 ~ 18.6 (140 ~ 190)
Large dia. side	9.52 (3/8") 12.7 (1/2")	34.3 ~ 44.1 (350 ~ 450) 44.1 ~ 53.9 (450 ~ 550)
Valve head cap	Small dia. side	6.35 (1/4")
	Large dia. side	9.52 (3/8") 12.7 (1/2")
Valve core cap		12.3 ~ 15.7 (125 ~ 160)

Gas Leakage Inspection

Please use gas leakage detector to check if leakage occurs at the connection of Flare nut as shown on the right.

If gas leakage occurs, further tighten the connection to stop leakage. (Use the detector provided for R410A)



3 Removal Of Air From The Pipe And Gas Leakage Inspection

Procedures of using Vacuum Pump for Air Removal


1 As shown in right figure, remove the cap of valve core. Then, connect the charge hose. Remove the cap of valve head. Connect the vacuum pump adapter to the vacuum pump and connect the charge hose to the adapter.

2 Fully tighten the "Hi" shuttle of the manifold valve and completely unscrew the "Lo" shuttle. Run the vacuum pump for about 10-15 minutes, then completely tighten the "Lo" shuttle and switch off the vacuum pump.


3 Completely unscrew the spindle of the service valve (at 2 places) in anti-clockwise direction to allow the flow of coolant (using Hexagonal Wrench key).

4 Remove the charge hose and tighten the cap of valve head. Check the cap's periphery if there is any gas leakage. The task is then completed.

When the meter reaches -101kPa (-76cmHg) during pumping, fully tighten the shuttle.



When pumping starts, slightly loosen the flare nut to check of air sucked in. Then tighten the flare nut.




WARNING • THIS APPLIANCE MUST BE EARTHED.

Power supply shall be connected at the rated voltage, otherwise the unit will be broken or could not reach the specified capacity.

Procedures of Wiring

In case that power is supplied from Outdoor Unit



WARNING

- The naked part of the wire core should be 10 mm and fix it to the terminal tightly. Then try to pull the individual wire to check if the contact is tight. Improper insertion may burn the terminal.
- Be sure to use only power cables approved from the authorities in your country. For example in Germany: Cable type: NYM 3x1.5mm².
- Please refer to the installation manual for wire connection to the terminals of the units. The cabling must meet the standards of electrical installation.
- There is a AC voltage of 230V between the L and N terminals. Therefore, before servicing, be sure to remove the plug from the AC outlet or switch off the main switch.

Wiring of The Outdoor Unit

- Please remove the side cover for wire connection.

WARNING

- If you cannot attach the side cover due to the connecting cord, press the connecting cord in direction to the front panel to fix it.
- Be sure that the hooks of the side cover is fixed in certainly. Otherwise water leakage may occur and this causes short circuit or faults.
- The connecting cord should not touch to service valve and pipes. (It becomes high temperature in heating operation.)


Checking for the electric source and the voltage range

- Before installation, the power source must be checked and necessary wiring work must be completed. To make the wiring capacity proper, use the wire gauges list below for the lead-in from a pole transformer and for the wiring from a switch board of fuse box to the main switch and outdoor unit in consideration of the locked rotor current.

IMPORTANT


Cable length	Wire cross-section
up to 6m	1.5mm ²
up to 15m	2.5mm ²
up to 25m	4.0mm ²

- Investigate the power supply capacity and other electrical conditions at the installation location. Depending on the model of room air conditioner to be installed, request the customer to make arrangements for the necessary electrical work etc. The electrical work includes the wiring work up the outdoor. In localities where electrical conditions are poor, use of a voltage regulation is recommended.



1 Insulation And Maintenance Of Pipe Connection

- The connected terminals should be completely sealed with heat insulator and then tied up with rubber strap.
- Please tie the pipe and power line together with vinyl tape as shown in the figure showing the installation of Indoor and Outdoor units. Then fix their position with holders.
- To enhance the heat insulation and to prevent water condensation, please cover the outdoor part of the drain hose and pipe with insulation pipe.
- Completely seal any gap with putty.



2 Power Source And Operation Test

Power Source

CAUTION

- Please use a new socket. Accident may occur due to the use of old socket because of poor contact.
- Please plug in and then remove the plug for 2 - 3 times. This is to ensure that the plug is completely plugged into the socket.
- Keep additional length for the power cord and do not render the plug under external force as this may cause poor contact.
- Do not fix the power cord with U-shape nail.

Operation Test

- Please ensure that the air conditioner is in normal operating condition during the operation test.
- Explain to your customer the proper operation procedures as described in the user's manual.

FOR SERVICE PERSONNEL ONLY

HITACHI
Inspire the Next

SPLIT UNIT AIR CONDITIONER INSTALLATION MANUAL

Indoor Unit



**RAK-25NH4
RAK-35NH4
RAK-50NH4**

- Carefully read through the procedures of proper installation before starting installation work.
- The sales agent should inform customers regarding the correct operation of installation.

Tools Needed For Installation Work

- ⊕ ⊖ Screwdriver • Measuring Tape • Knife
- Saw • ∅ 65mm Power Drill • Hexagonal Wrench Key (ㄩ 4mm) • Wrench (14, 17, 22, 26, 27mm)
- Gas Leakage Detector • Pipe Cutter • Putty
- Vinyl Tape • Pliers • Flare Tool

SAFETY PRECAUTION

- Read the safety precautions carefully before operating the unit.
- The contents of this section are vital to ensure safety. Please pay special attention to the following sign.

WARNING **Incorrect methods of installation may cause death or serious injury.**

CAUTION **Improper installation may result in serious consequence.**

Be sure that the unit operates in proper condition after installation. Explain to customer the proper way of operating the unit as described in the user's guide.

WARNING

- Please request your sales agent or qualified technician to install your unit. Water leakage, short circuit or fire may occur if you do the installation work yourself.
- Please observe the instructions stated in the installation manual during the process of installation. Improper installation may cause water leakage, electric shock and fire.
- Make sure that the units are mounted at locations which are able to provide full support to the weight of the units. If not, the units may collapse and impose danger.
- Observe the rules and regulations of the electrical installation and the methods described in the installation manual when dealing with the electrical work. Use power cables approved by the authorities of your country.
- Be sure to use the specified wire for connecting the indoor and outdoor units. Please ensure that the connections are tight after the conductors of the wire are inserted into the terminals. Improper insertion and loose contact may cause over-heating and fire.
- Please use the specified components for installation work. Otherwise, the units may collapse or water leakage, electric shock and fire may occur.
- Be sure to use the specified piping set for R-410A. Otherwise, this may result in broken copper pipes or faults.
- When installing or removing an air conditioner, only specified refrigerant (R410A) shall be allowed, do not allow air or moisture to remain in the refrigeration cycle. Otherwise, pressure in the refrigeration cycle may become abnormally high so that a rupture may be caused.
- Be sure to ventilate fully if a refrigerant gas leak while at work. If the refrigerant gas comes into contact with fire, a poisonous gas may occur.
- After completion of installation work, check to make sure that there is no refrigeration gas leakage. If the refrigerant gas leaks into the room, coming into contact with fire in the fan-driven heater, space heater, etc., a poisonous gas may occur.
- Unauthorized modifications to the air conditioner may be dangerous. If a breakdown occurs please call a qualified air conditioner technician or electrician. Improper repairs may result in water leakage, electric shock and fire, etc.

CAUTION

- A circuit breaker or fuse (16A time delay) must be installed. Without a circuit breaker or fuse the danger of electric shock exists. A main switch with a contact gap of more than 3mm has to be installed in the power supply line to the outdoor unit.
- Do not install the unit near a location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it.
- Please ensure smooth flow of water when installing the drain hose.
- Piping shall be suitable supported with a maximum spacing of 1m between the supports.



THE CHOICE OF MOUNTING SITE (Please note the following matters and obtain permission from customer before installation).

INDOOR UNIT










⚠ WARNING

- The unit should be mounted at stable, non-vibratory location which can provide full support to the unit.

⚠ CAUTION

- No nearby heat source and no obstruction near the air outlet is allowed.
- The clearance distances from top, right and left are specified in figure below.
- The location must be convenient for water drainage and pipe connection with the Outdoor unit.
- To avoid interference from noise please place the unit and its remote controller at least 1m from the radio, television and inverter type fluorescent lamp.
- To avoid any error in signal transmission from the remote controller, please put the controller far away from high-frequency machines and high-power wireless systems.
- The installation height of indoor unit must be 2.3m or more in a non public area.

Names of Indoor Components

No.	Item	Qty
①	Hanger 	1
②	Screw for Hanger (4.1x32) 	6
③	Holder for Remote Controller 	1
④	AAA Size Battery 	2
⑤	Screw for holder of Remote Controller (3.1x16) 	2
⑥	Insulation pipe 	1
⑦	Remote Controller 	1
⑧	Purifying Filter 	1
⑨	Holder 	1






Figure showing the Installation of Indoor Unit.


⚠ CAUTION

- The installation height of indoor unit must be 2.3m or more in a non public area.



- The difference in height between the indoor and outdoor unit should be kept max 5m.
- The connecting pipe, no matter big or small, should all be insulated with insulation pipe and then wrapped with vinyl tape. (The insulator will deteriorate if it is not wrapped with tape).

The connection of insulated drain hose.
inner diameter ϕ 16mm



Please use insulated drain hose for the indoor piping (commercial product).

The indoor piping should be insulated with the enclosed insulation pipe. (If the insulator is insufficient, please use commercial products).


1 Installation of Hanger, Wall Penetration and Installation of Protection Pipe

CAUTION

- The draining of the water container inside the indoor unit can be done from the left. Therefore the hanger must be fixed horizontally or slightly tilted towards the side of drain hose. Otherwise, condensed water may overflow the water container.


Direct Mounting On The Wall

- Please use hidden beams in the wall to hold the hanger.




Procedures of Installation and Precautions

- Procedures to fix the hanger.
 - Drill holes on wall. (As shown below)
 - Push plug into the holes. (As shown below)
 - Fix the hanger on wall with 4.1 x 32 screw (As shown in figure below)




- Procedures to fix the holder of remote control.
 - Drill holes on wall. (As shown below)
 - Push plug into the holes. (As shown below)



Wall Penetration and Installation of Protection Pipe

- Drill a ϕ 65mm hole on wall which is slightly tilted towards the outdoor side. Drill the wall at a small angle.
- Cut the protection pipe according to the wall thickness.
- Empty gap in the sleeve of protection pipe should be completely sealed with putty to avoid dripping of rain water into the room.




WARNING
Be sure that the wire is not in contact with any metal in the wall. Please use the protection pipe as wire passing through the hollow part of the wall so as to prevent the possibility of damaged by mouse. Unless it seals completely, any air with high humidity flows from outdoor and any dew may drop.

2 Installation of the Indoor Unit

VERTICALLY DOWNWARD PIPING


Preparation

- Connect connecting cord.
- Pull out the pipe, connecting cord and drain hose.



Installation


- The upper part of the Indoor unit is hanged on the hanger.
- The projection at the lower part of the Indoor unit is hooked onto the hanger.



CAUTION
Please pull the lower part of the Indoor unit outwards to check if the unit is hooked onto the hanger. Improper installation may cause vibration and noise.

HOW TO REMOVE INDOOR UNIT FROM HANGER

- Pull down PULL section on the bottom of indoor unit and pull it towards you, then claws are released from hanger. (Indicated by 2 arrows in the drawing on the right.)
- When bottom face of indoor unit cannot be pulled due to obstacles, etc. Remove front cover, insert screw driver into circle hole, pull claws down and pull indoor unit towards you.
- Please check how to remove and attach front cover in this instruction manual.




HORIZONTAL PIPING

Preparation

Change of Drain Hose and Installation Procedures.


- Exchange the location of drain hose and drain cap during horizontal piping as shown in figure below. Be sure to plug in the drain hose until the insulating material folds upon itself.
- Please use pliers to pull out the drain cap. (This is an easier way to remove the drain cap.)



CAUTION Condensed water may leak out if not inserted properly.


HORIZONTAL & DOWNWARD PIPING – MAKING OPENINGS

- During horizontal or downward piping, use a knife to cut openings as shown in figure. Then smoothen the edges of openings with a file.
- Turn the piping while holding down the lower portion of pipe-support by hand.




INSTALLATION OF REFRIGERATING PIPES AFTER CONNECTION

- The refrigerating pipes should be adjusted to fit into the hole on the wall and then ready for further connection.
- The terminals of 2 connected pipes must be covered with insulator used for terminal connection. Then the pipes are wrapped with insulation pipe.
- Connect the connecting cord after removing electrical cover. (Refer to "CONNECTION OF POWER CORD")
- After adjustment, fit the connecting cord and pipes into the space available under the indoor unit. Use holder to hold them tight.



CAUTION
The rubber strap used for fixing the insulator should not be tied with great force. Otherwise, this will damage heat insulation and causes water condensation.



THE CONNECTION OF REFRIGERATING PIPE DURING THE INSTALLATION OF INDOOR UNIT

Preparation To Install Refrigerating Pipes



- The refrigerating pipes and connecting cord transform and are attached.
- The end of the refrigerating pipes are at locations marked with "▽" symbol.

CAUTION
Please fix in the plastic core after flaring to avoid plastic chips entering the pipes.




Installation

- Hang the Indoor unit onto the hanger. Use the temporary stand at the back of the Indoor unit to push its lower part 15cm forwards.
- Place the drain hose through the hole on the wall.
- Wrap the refrigerating pipes with insulation pipe after connecting refrigerating pipe.
- Connect the connecting cord after removing electrical cover. (Refer to "Connection of Power Cord")
- After adjustment, the connecting cord and refrigerating pipes are placed into the space available under the Indoor unit.
- The projection of Indoor unit must hook to the hanger.



3 Installation of Drain Hose




CAUTION
Be sure that the drain hose is not loosely connected or bend.

CAUTION You are free to choose the side (left or right) for the installation of drain hose. Please ensure the smooth flow of condensed water of the Indoor unit during installation. (Carelessness may result in water leakage.)

1 Preparation of Pipe


- Use a pipe cutter to cut the copper pipe.



CAUTION

- Jagged edge will cause leakage.
- Point the side to be trimmed downwards during trimming to prevent copper chips from entering the pipe.

- Before flaring, please put on the flare nut.




- Recommend to use R410A flaring tool.

Outer Diameter (mm)	A (mm)	
	For R410A tool	For R22 tool
6.35	0.0 ~ 0.5mm	1.0mm
9.52	0.0 ~ 0.5mm	1.0mm
12.7	0.0 ~ 0.5mm	1.0mm

2 Pipe Connection

CAUTION

In case of removing flare nut of an Indoor unit, first remove a nut of small diameter side, or a seal cap of big diameter side will fly out. Prevent water from entering into the piping when working.




	Outer dia. of pipe	Torque N·m (kgf · cm)
Small dia. side	6.35 (1/4")	13.7 - 18.6 (140 - 190)
Large dia. side	9.52 (3/8")	34.3 - 44.1 (350 - 450)
	12.7 (1/2")	44.1 - 53.9 (450 - 550)
Valve head cap	Small dia. side	6.35 (1/4")
	Large dia. side	9.52 (3/8")
Valve core cap	Small dia. side	6.35 (1/4")
	Large dia. side	9.52 (3/8")
		12.3 - 15.7 (125 - 160)

3 Removal Of Air From The Pipe And Gas Leakage Inspection

Procedures of using Vacuum Pump for Air Removal

- As shown in right figure, remove the cap of valve core. Then, connect the charge hose. Remove the cap of valve head. Connect the vacuum pump adapter to the vacuum pump and connect the charge hose to the adapter.
- Fully tighten the "Hi" shuttle of the manifold valve and completely unscrew the "Lo" shuttle. Run the vacuum pump for about 10-15 minutes, then completely tighten the "Lo" shuttle and switch off the vacuum pump.
- Completely unscrew the spindle of the service valve (at 2 places) in anti-clockwise direction to allow the flow of coolant (using Hexagonal Wrench key).
- Remove the charge hose and tighten the cap of valve head. Check the cap's periphery if there is any gas leakage. The task is then completed.


When the meter reaches -101KPa (-76cmHg) during pumping, fully tighten the shuttle.




When pumping starts, slightly loosen the flare nut to check of air sucked in. Then tighten the flare nut.

Gas Leakage Inspection

Please use gas leakage detector to check if leakage occurs at the connection of Flare nut as shown on the right.



If gas leakage occurs, further tighten the connection to stop leakage. (Use the detector provided for R410A).




WARNING THIS APPLIANCE MUST BE EARTHED.

Power supply shall be connected at the rated voltage, otherwise the unit will be broken or could not reach the specified capacity.

Procedures of Wiring

In case that power is supplied from Indoor Unit



WARNING

- The naked part of the wire core should be 10 mm and fix it to the terminal tightly. Then try to pull the individual wire to check if the contact is tight. Improper insertion may burn the terminal.
- Be sure to use only power cables approved from the authorities in your country. For example in Germany: Cable type: NYM 3x1.5mm².
- Please refer to the installation manual for wire connection to the terminals of the units. The cabling must meet the standards of electrical installation.
- There is a AC voltage of 230V between the L and N terminals. Therefore, before servicing, be sure to remove the plug from the AC outlet or switch off the main switch.

Wiring Of The Indoor Unit


- For wire connection of the Indoor unit, you need to remove front panel and electrical cover.

Method to remove front panel

- Refer to "FINAL STAGE OF INSTALLATION - How to Remove The Front Cover".


Method to remove electrical cover

- Remove the screw and electrical cover.
- Insert the connecting cord (C, D) from the bottom of unit.
- Fixed the wire to terminal wires firmly as shown in figure at right side.



Connect the earth cord

After remove the screw and band, put the connecting cords and fix the band with screw.



Checking for the electric source and the voltage range


- Before installation, the power source must be checked and necessary wiring work must be completed. To make the wiring capacity proper, use the wire gauges list below for the lead-in from a pole transformer and for the wiring from a switch board of fuse box to the main switch and outdoor unit in consideration of the locked rotor current.

Cable length	Wire cross-section
up to 6m	1.5mm ²
up to 15m	2.5mm ²
up to 25m	4.0mm ²

IMPORTANT

1 Insulation And Maintenance Of Pipe Connection

- The connected terminals should be completely sealed with heat insulator and then tied up with rubber strap.
- Please tie the pipe and power line together with vinyl tape as shown in the figure showing the installation of Indoor and Outdoor units. Then fix their position with holders.
- To enhance the heat insulation and to prevent water condensation, please cover the outdoor part of the drain hose and pipe with insulation pipe.
- Completely seal any gap with putty.



3 Power Source And Operation Test

Power Source


CAUTION

- Please use a new socket. Accident may occur due to the use of old socket because of poor contact.
- Please plug in and then remove the plug for 2 – 3 times. This is to ensure that the plug is completely plugged into the socket.
- Keep additional length for the power cord and do not render the plug under external force as this may cause poor contact.
- Do not fix the power cord with U-shape nail.

2 Installation Of Remote Controller

- The remote controller can be placed in its holder which is fixed on wall or beam.
- To operate the remote controller at its holder, please ensure that the unit can receive signal transmitted from the controller at the place where the holder is to be fixed. The unit will beep when signal is received from the remote controller. The signal transmission is weakened by the fluorescent light. Therefore, during the installation of the remote control holder, please switch on the light, even during day time, to determine the mounting location of the holder.

The controller must be hooked onto the hook at the lower part of the holder. Push in the remote controller in the direction as shown in figure below.




Operation Test

- Please ensure that the air conditioner is in normal operating condition during the operation test.
- Explain to your customer the proper operation procedures as described in the user's manual.


How to Remove The Front Cover

- 1 Remove the front panel.
 - Please remove and attach the front panel by both hands.




- After opening the front panel by both hands.
 - 1 Undo the right arm while pushing it inside.
 - 2 Slide the front panel to right as shown in figure. Then remove while pulling it to front.


- 2 Remove the filters.
- 3 Remove the caps and screws at the lower portion of the front cover.



- 4 Pull the front cover upward as far as the location where the lower portion of the front cover is on the deflector.




- 5 Remove while pulling the front cover in direction to arrow as shown in figure to hold the both sides of front cover.




How to Attach the Front Cover

- 1 After covering the front cover to the unit, certainly hook at the upper portion (three places). Then, check that the drain pan is certainly attached. Push the center of front cover in the direction of arrow.



- 2 Fix the front cover at lower portion by screws and attach the caps.


- 3 Attach the front panel.



- Certainly insert the left shaft of the front panel to the hole of the front cover. Next insert the right shaft as same as the left.


- 4 Attach the filters which are placed the surface written "FRONT" up.

- After attaching the filters, push the front panel at three arrow portion as shown in figure and close it.




SAFETY DURING REPAIR WORK

1. In order to disassemble and repair the unit in question, be sure to disconnect the power cord plug from the power outlet before starting the work.



2. If it is necessary to replace any parts, they should be replaced with respective genuine parts for the unit, and the replacement must be effected in correct manner according to the instructions in the Service Manual of the unit.

If the contacts of electrical parts are defective, replace the electrical parts without trying to repair them.



3. After completion of repairs, the initial state should be restored.
4. Lead wires should be connected and laid as in the initial state.
5. Modification of the unit by user himself should absolutely be prohibited.
6. Tools and measuring instruments for use in repairs or inspection should be accurately calibrated in advance.
7. In installing the unit having been repaired, be careful to prevent the occurrence of any accident such as electrical shock, leak of current, or bodily injury due to the drop of any part.
8. To check the insulation of the unit, measure the insulation resistance between the power cord plug and grounding terminal of the unit. The insulation resistance should be $1M\Omega$ or more as measured by a 500V DC megger.
9. The initial location of installation such as window, floor or the other should be checked for being and safe enough to support the repaired unit again. If it is found not so strong and safe, the unit should be installed at the initial location reinforced or at a new location.
10. Any inflammable thing should never be placed about the location of installation.
11. Check the grounding to see whether it is proper or not, and if it is found improper, connect the grounding terminal to the earth.



WORKING STANDARDS FOR PREVENTING BREAKAGE OF SEMICONDUCTORS

1. Scope

The standards provide for items to be generally observed in carrying and handling semiconductors in relative manufacturers during maintenance and handling thereof. (They apply the same to handling of abnormal goods such as rejected goods being returned).

2. Object parts

- (1) Micro computer
- (2) Integrated circuits (IC)
- (3) Field-effect transistors (FET)
- (4) P.C. boards or the like on which the parts mentioned in (1) and (2) of this paragraph are equipped.

3. Items to be observed in handling

- (1) Use a conductive container for carrying and storing of parts. (Even rejected goods should be handled in the same way).




Fig. 1. Conductive Container

- (2) When any part is handled uncovered (in counting, packing and the like), the handling person must always use himself as a body earth. (Make yourself a body earth by passing one M ohm earth resistance through a ring or bracelet).
- (3) Be careful not to touch the parts with your clothing when you hold a part even if a body earth is being taken.
- (4) Be sure to place a part on a metal plate with grounding.
- (5) Be careful not to fail to turn off power when you repair the printed circuit board. At the same time, try to repair the printed circuit board on a grounded metal plate.




Fig. 2. Body Earth

(6) Use a three wire type soldering iron including a grounding wire.




Fig. 3. Grounding of the working table




Fig. 4. Grounding a soldering iron

Use a high insulation mode (100V, 10MΩ or higher) when ordinary iron is to be used.

(7) In checking circuits for maintenance, inspection or some others, be careful not to have the test probes of the measuring instrument shortcircuit a load circuit or the like.

 **CAUTION**


1. In quiet operation or stopping the running, slight flowing noise of refrigerant in the refrigerating cycle is heard occasionally, but this noise is not abnormal for the operation.
2. When it thunders near by, it is recommend to stop the operation and to disconnect the power cord plug from the power outlet for safety.
3. The room air conditioner does not start automatically after recovery of the electric power failure for preventing fuse blowing. Re-press START/STOP button after 3 minutes from when unit stopped.
4. If the room air conditioner is stopped by adjusting thermostat, or missoperation, and re-start in a moment, there is occasion that the cooling and heating operation does not start for 3 minutes, it is not abnormal and this is the result of the operation of IC delay circuit. This IC delay circuit ensures that there is no danger of blowing fuse or damaging parts even if operation is restarted accidentally.
5. This room air conditioner should not be used at the cooling operation when the outside temperature is below 10°C (50°F).
6. This room air conditioner (the reverse cycle) should not be used when the outside temperature is below -10°C (14°F).
If the reverse cycle is used under this condition, the outside heat exchanger is frosted and efficiency falls.
7. When the outside heat exchanger is frosted, the frost is melted by operating the hot gas system, it is not trouble that at this time fan stops and the vapour may rise from the outside heat exchanger.

SPECIFICATIONS

MODEL		RAK-25NH4 RAK-35NH4 RAK-50NH4	RAC-25NH4	RAC-35NH4	RAC-50NH4
FAN MOTOR		PWM DC35V	40 W		
FAN MOTOR CAPACITOR		NO	NO		
FAN MOTOR PROTECTOR		NO	NO		
COMPRESSOR		-	JU1012D	JU1013D	
COMPRESSOR MOTOR CAPACITOR		NO	NO		
OVERLOAD PROTECTOR		NO	YES		
OVERHEAT PROTECTOR		NO	YES		
FUSE (for MICROPROCESSOR)		NO	3.0A		
POWER RELAY		NO	G4A		
POWER SWITCH		NO	NO		
TEMPORARY SWITCH		YES	NO		
SERVICE SWITCH		NO	YES		
TRANSFORMER		NO	NO		
VARISTOR		NO	450NR		
NOISE SUPPRESSOR		NO	YES		
THERMOSTAT		YES(IC)	YES(IC)		
REMOTE CONTROL SWITCH (LIQUID CRYSTAL)		YES	NO		
REFRIGERANT CHARGING VOLUME (Refrigerant 410A)	UNIT	-----	1150g	1150g	1400g
	PIPES (MAX. 20m)	WITHOUT REFRIGERANT BECAUSE COUPLING IS FLARE TYPE.			


CONSTRUCTION AND DIMENSIONAL DIAGRAM

MODEL RAK-25NH4, RAK-35NH4, RAK-50NH4




CONSTRUCTION AND DIMENSIONAL DIAGRAM FOR OUTDOOR

MODEL RAC-25NH4, RAC-35NH4



MODEL RAC-50NH4



MAIN PARTS COMPONENT



THERMOSTAT

Thermostat Specifications

MODEL			RAK-25NH4, RAK-35NH4, RAK-50NH4	
THERMOSTAT MODEL			IC	
OPERATION MODE			COOL	HEAT
TEMPERATURE °C (°F)	INDICATION 16	ON	15.6 (60.1)	20.0 (68.0)
		OFF	15.3 (59.5)	20.7 (69.3)
	INDICATION 24	ON	23.6 (74.5)	28.0 (82.4)
		OFF	23.3 (73.9)	28.7 (83.7)
	INDICATION 32	ON	31.6 (88.9)	36.0 (96.8)
		OFF	31.3 (88.3)	36.7 (98.1)

FAN MOTOR

Fan Motor Specifications

MODEL	RAK-25NH4, RAK-35NH4, RAK-50NH4	RAC-25NH4, RAC-35NH4, RAK-50NH4
POWER SOURCE	DC: 0 ~ 35V	DC360V
OUTPUT	23W	40W
CONNECTION	 <p>(Control circuit built in)</p>	

BLU : BLUE

YEL : YELLOW

BRN : BROWN

WHT : WHITE

GRY : GRAY

ORN : ORANGE

GRN : GREEN

RED : RED

BLK : BLACK


PNK : PINK

VIO : VIOLET

COMPRESSOR MOTOR

Compressor Motor Specifications

MODEL	RAC-25NH4	RAC-35NH4	RAC-50NH4
COMPRESSOR MODEL	JU1012D		JU1013D
PHASE	SINGLE		
RATED VOLTAGE	AC 220 ~ 230 V		
RATED FREQUENCY	50 Hz		
POLE NUMBER	4		
CONNECTION			
RESISTANCE VALUE (Ω)	20°C (68°F)	2M = 1.05	
	75°C (167°F)	2M = 1.28	




CAUTION

When the refrigerating cycle has been operated for a long time with the capillary tubes clogged or crushed or with too little refrigerant, check the color of the refrigerating machine oil inside the compressor. If the color has been changed conspicuously, replace the compressor.


WIRING DIAGRAM

MODEL RAK-25NH4 / RAC-25NH4
 RAK-35NH4 / RAC-35NH4
 RAK-50NH4 / RAC-50NH4

INDOOR UNIT




OUTDOOR UNIT



CIRCUIT DIAGRAM

Remote Control




Key matrix table

Input \ Output		D0	D1	D2	D3
P10	Door open	Start/Stop	Operation selection	Fan speed selection	Automatic swing
	Door shut	Start/Stop	Automatic swing	-	-
P11	Door open	On timer	Hour up	Hour down	Day • present time
	Door shut	-	Room temperature up	Room temperature down	Fan speed
P12	Door open	Off timer	-	Reservation	Cancel
	Door shut	Sleep	-	-	-

CIRCUIT DIAGRAM

MODEL RAK-25NH4, RAK-35NH4, RAK-50NH4



NOTES:
1. TYPE ØF CAPACITOR

F : FILM
C : CERAMIC
D : ELECTROLYTIC

2. FORM
H : HAND INSERT
C : SMT
R : RADIAL
A : AXIAL

RESISTOR

SYMBOL	RESISTANCE	TOL.	POWER	FORM
R111	27K	±5%	1/16W	C
R112	30K	±5%	1/16W	C
R114	750	±5%	1/8W	C
R115	560	±5%	1/8W	C
R116	75K	±2%	1/16W	C
R117	68K	±5%	1/16W	C
R118	75K	±2%	1/16W	C
R119	6.8K	±2%	1/16W	C
R120				
R121	0.56	±5%	1/4W	C
R122	100	±5%	1/16W	C
R123	33K	±5%	1/16W	C
R124	100	±5%	1/16W	C
R125				
R126				
R127				
R128	10K	±5%	1/16W	C
R131				
R132	JUMPER	-	1/16W	C
R201	1K	±5%	1/10W	C
R219	3.3K	±5%	1/10W	C
R301	12.7K	±1%	1/16W	C
R302	12.7K	±1%	1/16W	C
R303	10K	±5%	1/16W	C
R305	1K	±5%	1/16W	C
R306	1K	±5%	1/16W	C

SYMBOL	RESISTANCE	TOL.	POWER	FORM
R307	1K	±5%	1/16W	C
R308	10K	±5%	1/16W	C
R401	390	±5%	1/16W	C
R402	390	±5%	1/16W	C
R403	5.1K	±5%	1/16W	C
R404	5.1K	±5%	1/16W	C
R500	10K	±5%	1/16W	C
R501	1M	±5%	1/16W	C
R502	0	±5%	1/16W	C
R503	10K	±5%	1/16W	C
R504	10K	±5%	1/16W	C
R505	10K	±5%	1/16W	C
R506	10K	±5%	1/16W	C
R507	10K	±5%	1/16W	C
R508	10K	±5%	1/16W	C
R509	10K	±5%	1/16W	C
R510	10K	±5%	1/16W	C
R511	10K	±5%	1/16W	C
R512	10K	±5%	1/16W	C
R513	10K	±5%	1/16W	C
R514	10K	±5%	1/16W	C
R515	10K	±5%	1/16W	C
R521	1M	±5%	1/16W	C
R522	1K	±5%	1/16W	C
R601	1K	±5%	1/16W	C
R602	10K	±5%	1/16W	C
R603	10K	±5%	1/16W	C

SYMBOL	RESISTANCE	TOL.	POWER	FORM
R604	10K	±5%	1/16W	C
R605	10K	±5%	1/16W	C
R606	10K	±5%	1/16W	C
R609				
R610	10K	±5%	1/16W	C
R611	1K	±5%	1/16W	C
R612	10K	±5%	1/16W	C
R631	1K	±5%	1/16W	C
R641	10K	±5%	1/16W	C
R650	1K	±5%	1/16W	C
R651	1K	±5%	1/16W	C
R652	100	±5%	1/16W	C
R653	1K	±5%	1/16W	C
R654	10K	±5%	1/16W	C
R655	10K	±5%	1/16W	C
R656	10K	±5%	1/16W	C
R657	10K	±5%	1/16W	C
R658	10K	±5%	1/16W	C
R701	1K	±5%	1/16W	C
R741	110	±5%	1/10W	C
R742	110	±5%	1/10W	C
R743	110	±5%	1/10W	C
R744	130	±5%	1/10W	C
R745	130	±5%	1/10W	C
R746	130	±5%	1/10W	C

SYMBOL	RESISTANCE	TOL.	POWER	FORM
R747	5.1K	±5%	1/16W	C
R748	5.1K	±5%	1/16W	C
R749	5.1K	±5%	1/16W	C
R751	2.7K	±5%	1/16W	C
R761				
R763	10K	±5%	1/16W	C
R764	1K	±5%	1/16W	C
R803	120K	±5%	1/16W	C
R804	120K	±5%	1/16W	C
R805	120K	±5%	1/16W	C
R806	120K	±5%	1/16W	C
R807	4.3K	±5%	1/16W	C
R810	680	±5%	1/10W	C
R811	2K	±5%	1/16W	C
R812	39	±5%	1/8W	C
R813	39	±5%	1/8W	C
R821	1K	±5%	1/16W	C
R822	10K	±1%	1/16W	C
R823	10K	±1%	1/16W	C
R824	8.25K	±1%	1/16W	C
R825	10K	±1%	1/16W	C
R826	1K	±5%	1/16W	C
R827	3K	±5%	1/16W	C
R828	10K	±5%	1/16W	C
R829	5.1K	±5%	1/16W	C
R830	1K	±5%	1/16W	C
R1	47	±5%	1/10W	C
R2	1K	±5%	1/16W	C

SYMBOL	CAPACITANCE	TOL.	TYPE	FORM
C101	0.22µ	±5%	F	H
C102	330µ	±5%	D (PF)	H
C103	470P	±5%	C	C
C104				
C111	2.2µ	±5%	10V	C
C112	1000P	±5%	C	C
C113	0.047µ	±5%	25V	C
C114	220µ	±5%	35V	H
C115				
C116				
C121	0.1µ	±5%	25V	C
C122	100µ	±5%	10V	H
C123	0.1µ	±5%	25V	C
C131	0.22µ	±5%	50V	C
C132	0.1µ	±5%	25V	C
C133				
C302	0.1µ	±5%	25V	C
C303	0.1µ	±5%	25V	C
C304	0.1µ	±5%	25V	C
C401	0.1µ	±5%	25V	C
C501	0.1µ	±5%	25V	C
C502	0.1µ	±5%	25V	C
C505	0.1µ	±5%	25V	C
C506	0.1µ	±5%	25V	C
C507	0.1µ	±5%	25V	C

SYMBOL	CAPACITANCE	TOL.	TYPE	FORM	
C521	0.1µ	±5%	25V	C	
C522	0.22µ	±5%	10V	C	
C523	0.1µ	±5%	25V	C	
C524	0.1µ	±5%	25V	C	
C601	0.1µ	±5%	25V	C	
C611	1000P	±5%	C	C	
C621					
C631	1000P	±5%	C	C	
C651	0.1µ	±5%	25V	C	
C711	0.1µ	±5%	25V	C	
C751	1µ	±5%	16V	C	
C762					
C763	0.1µ	±5%	25V	C	
C801	150P	±5%	C	C	
C802	0.22µ	±5%	50V	F	H
C803	0.1µ	±5%	25V	C	C
C804					
C821	0.01µ	±5%	20V	F	H
C822	1000P	±5%	C	C	
C823	0.047µ	±5%	25V	C	C
C824	0.01µ	±5%	50V	C	C
C825	0.1µ	±5%	25V	C	C
C1	33µ	±5%	10V	H	H

SYMBOL	MODEL	FORM
IC111	NJM2340M	C
REG2	MC7805CT	H
IC401	BR24C02F	C
IC402	S24C08DP	H
IC501	AX-7R1	C
IC521	RM5VD42C	C
IC711	ULN2003ANS	C
IC801	NJM2903M	C
IR1	RP69238-V4	H

SYMBOL	MODEL	COLOR	FORM
LD721	SEL6914A	YEL	H
LD723	SEL6214S	RED	H
LD725	SEL6414E	GRN	H
ICP3			
ICPS			
ICP1	CCP2E-20	0.8A	C
ICP2	CCP2E-50	2.0A	C
ICP3			
OSCILLATOR			
RES1	CS150MHz	10MHz	H
ZENER DIODE			
ZD111	RD6.2UJN2		C
ZD121	PTZ20A		C
ZD131	RLZ6.8A		C
ZD211	RD5.1UJN2		C
BUZZER			
BZ	PKM13EPY		H
SWITCH			
SW1	EVQ090K		H


SYMBOL	MODEL	FORM
D101	G4DL-6140	H
D111	D1FS6	C
D401		C
D403		C
D402	1SS395	C
DB21	1SS395	C

SYMBOL	INDUCTANCE	C. RATING	FORM
L101	B2#	1.3A	H
L111	560µ	0.4A	H
L501	ØHP JUMPER	-	C
L741	ØHP JUMPER	-	C
L742	ØHP JUMPER	-	C
L743	ØHP JUMPER	-	C
L751	ØHP JUMPER	-	C
L801	100µ	55mA	C

SYMBOL	USAGE	FORM
J801	NONE	C

CIRCUIT DIAGRAM

MODEL RAC-25NH4/RAC-35NH4/RAC-50NH4



COMPONENT TYPE
 C: CERAMIC
 F: FILM
 D: ELECTROLYTIC
 A: AXIAL
 R: RADIAL (R1,R2)
 P: RADIAL (7.5MM PITCH)
 H: MANUAL INSERT
 HIC: HYBRID IC
 M: MAIN BOARD

RESISTORS

MARK	RATING (TR)	(%T/W)	REMARK
R001	470K	5% 1/4 A M	
R002	2.2	5% 1/4 A M	
R003	5.6K	5% 1/4 A M	
R004	169K	5% 1/4 A M	
R005	10K	5% 1/4 A M	
R006	100	5% 1/4 A M	
R007	100	5% 1/4 A M	
R008	100	5% 1/4 A M	
R009	470K	5% 1/4 A M	
R010	470K	5% 1/4 A M	
R011	470K	5% 1/4 A M	

RESISTORS

MARK	RATING (TR)	(%T/W)	REMARK
R101	3.6K	1% 1/4 A M	
R102	30K	5% 1/4 A M	
R103	30K	5% 1/4 A M	
R104	3.9K	5% 1/4 A M	
R105	7.5K	5% 1/4 A M	
R106	2.4K	5% 1/4 A M	
R107	1	1% 2 P M	
R108	510	5% 1/4 A M	

RESISTORS

MARK	RATING (TR)	(%T/W)	REMARK
R200	10K	5% 1/4 A M	
R201	10K	5% 1/4 A M	
R202	10K	5% 1/4 A M	
R203	390	5% 1/4 A M	
R204	390	5% 1/4 A M	
R205	10K	5% 1/4 A M	
R206	10K	5% 1/4 A M	
R207	10K	5% 1/4 A M	
R208	10K	5% 1/4 A M	
R209	10K	5% 1/4 A M	
R210	10K	5% 1/4 A M	
R211	10K	5% 1/4 A M	
R212	390	5% 1/4 A M	
R213	10K	5% 1/4 A M	
R214	10K	5% 1/4 A M	
R215	10K	5% 1/4 A M	
R216	10K	5% 1/4 A M	

CAPACITORS

MARK	RATING (UF/TV)	(%T/W)	REMARK
C001	0.01	25	C P M
C002	0.01	25	C P M
C003	0.01	25	C P M
C004	0.01	25	C P M
C005	0.01	25	C P M
C006	4	400	F H M VR
C007	0.01	25	C P M
C008	0.01	25	C P M
C009	0.1	50	C R M
C010	100	250	D R M
C011	100	250	D R M
C012	0.01	25	C R M
C013	0.01	25	C R M
C014	0.01	25	C R M
C015	0.01	25	C R M

LEDS

MARK	M0DEL	REMARK
L001	FB040MA250	A H M
L002	FB040MA250	A H M
L003	1015-2013A1	A H M
L004	TA01303615-03171	A H M
L801	T001	H M
L802	FB040MA250	A H M
L803	CR204	A H M
L804	CH157	A H M
L901	BLOBN1	A H M
L902	JUMPER	A H M
L903	JUMPER	A H M
L904	JUMPER	A H M
CT1	PCN01906-03161	H M
T1	THH4010	H M

ZENER DIODES

MARK	M0DEL	REMARK
ZD101	H212EPTK	H M
ZD102	H212EPTK	H M
ZD904		

OSCILLATOR

MARK	M0DEL	REMARK
X1	IC1CV60003	C HIC M

RESISTORS

MARK	RATING (TR)	(%T/W)	REMARK
R195	1K	5% 1/4 A M	
R196	1K	5% 1/4 A M	
R197	1K	5% 1/4 A M	
R198	1K	5% 1/4 A M	
R199	1K	5% 1/4 A M	
R200	10K	5% 1/4 A M	
R201	10K	5% 1/4 A M	
R202	10K	5% 1/4 A M	
R203	390	5% 1/4 A M	
R204	390	5% 1/4 A M	
R205	10K	5% 1/4 A M	
R206	10K	5% 1/4 A M	
R207	10K	5% 1/4 A M	
R208	10K	5% 1/4 A M	
R209	10K	5% 1/4 A M	
R210	10K	5% 1/4 A M	
R211	10K	5% 1/4 A M	
R212	390	5% 1/4 A M	
R213	10K	5% 1/4 A M	
R214	10K	5% 1/4 A M	
R215	10K	5% 1/4 A M	
R216	10K	5% 1/4 A M	

RESISTORS

MARK	RATING (TR)	(%T/W)	REMARK
R501	1K	5% 1/4 A M	
R502	1K	5% 1/4 A M	
R503	1K	5% 1/4 A M	
R504	1K	5% 1/4 A M	
R505	1K	5% 1/4 A M	
R506	1K	5% 1/4 A M	
R507	5.6K	5% 1/4 A M	
R508	5.6K	5% 1/4 A M	
R509	5.6K	5% 1/4 A M	
R510	5.6K	5% 1/4 A M	
R511	5.6K	5% 1/4 A M	
R512	5.6K	5% 1/4 A M	
R513	5.6K	5% 1/4 A M	
R514	5.6K	5% 1/4 A M	
R515	5.6K	5% 1/4 A M	
R516	5.6K	5% 1/4 A M	

CAPACITORS

MARK	RATING (UF/TV)	(%T/W)	REMARK
C201	0.047	25	C C HIC M
C202	0.047	25	C C HIC M
C203	0.047	25	C C HIC M
C204	0.047	25	C C HIC M
C205	1	50	D R M VR
C206	0.047	25	C C HIC M
C207	0.047	25	C C HIC M
C208	0.047	25	C C HIC M
C209	0.047	25	C C HIC M
C210	0.047	25	C C HIC M
C211	0.047	25	C C HIC M
C212	0.047	25	C C HIC M
C213	0.047	25	C C HIC M
C214	0.047	25	C C HIC M
C215	0.047	25	C C HIC M
C216	0.047	25	C C HIC M
C217	0.047	25	C C HIC M
C218	0.047	25	C C HIC M
C219	0.047	25	C C HIC M
C220	0.047	25	C C HIC M
C221	0.1	50	C C HIC M
C222	0.1	50	C C HIC M
C223	0.1	50	C C HIC M
C224	0.1	50	C C HIC M
C225	0.1	50	C C HIC M
C226	0.1	50	C C HIC M
C227	2200	50	C C HIC M

TRANSISTORS

MARK	M0DEL	REMARK
D001	2SA4673	C HIC M
D002	DT114YSATP	R M
D003	2SC3246	R M
D201	2SC2462L	C HIC
D202	2SC2462L	C HIC
D203	2SC2462L	C HIC
D204	2SC2462L	C HIC
D205	2SC2462L	C HIC
D206	2SC2462L	C HIC
D207	2SC2462L	C HIC
D208	2SC2462L	C HIC
D209	2SC2462L	C HIC
D210	2SC2462L	C HIC
D211	2SC2462L	C HIC
D212	2SC2462L	C HIC
D213	2SC2462L	C HIC
D214	2SC2462L	C HIC
D215	2SC2462L	C HIC
D216	2SC2462L	C HIC
D217	2SC2462L	C HIC
D218	2SC2462L	C HIC
D219	2SC2462L	C HIC
D220	2SC2462L	C HIC
D221	2SC2462L	C HIC
D222	2SC2462L	C HIC
D223	2SC2462L	C HIC
D224	2SC2462L	C HIC
D225	2SC2462L	C HIC
D226	2SC2462L	C HIC
D227	2SC2462L	C HIC

JUMPERS

MARK	M0DEL	REMARK
JW2	EXIST	A H M
JW3	NONE	A H M
JW4	CHIP JUMPER	C HIC
JW6	NONE	A H M
JW8	EXIST	A H M
JW9	NONE	A H M
JW10	CHIP JUMPER	C HIC

RESISTORS

MARK	RATING (TR)	(%T/W)	REMARK
R300	100	5% 1/4 A M	
R301	3.7K	1% 1/4 A M	
R302	3.0K	1% 1/4 A M	
R303	3.0K	1% 1/4 A M	
R304	100	5% 1/4 A M	
R305	100	5% 1/4 A M	
R306	100	5% 1/4 A M	
R307	100	5% 1/4 A M	

RESISTORS

MARK	RATING (TR)	(%T/W)	REMARK
R601	2K	5% 1/4 A M	
R602	2K	5% 1/4 A M	
R603	2K	5% 1/4 A M	
R604	100	5% 1/4 A M	
R605	100	5% 1/4 A M	
R606	100	5% 1/4 A M	
R607	100	5% 1/4 A M	
R608	100	5% 1/4 A M	
R609	100	5% 1/4 A M	
R610	100	5% 1/4 A M	
R611	100	5% 1/4 A M	
R612	100	5% 1/4 A M	
R613	100	5% 1/4 A M	
R614	100	5% 1/4 A M	
R615	100	5% 1/4 A M	
R616	100	5% 1/4 A M	
R617	100	5% 1/4 A M	
R618	100	5% 1/4 A M	
R619	100	5% 1/4 A M	
R620	100	5% 1/4 A M	
R621	100	5% 1/4 A M	
R622	100	5% 1/4 A M	
R623	100	5% 1/4 A M	
R624	100	5% 1/4 A M	
R625	100	5% 1/4 A M	
R626	100	5% 1/4 A M	
R627	100	5% 1/4 A M	
R628	100	5% 1/4 A M	
R629	100	5% 1/4 A M	
R630	100	5% 1/4 A M	
R631	100	5% 1/4 A M	
R632	100	5% 1/4 A M	
R633	100	5% 1/4 A M	
R634	100	5% 1/4 A M	
R635	100	5% 1/4 A M	
R636	100	5% 1/4 A M	

CAPACITORS


MARK	RATING (UF/TV)	(%T/W)	REMARK
C301	0.1	16	C C HIC M
C302	0.1	16	C C HIC M
C303	0.1	16	C C HIC M
C304	0.1	16	C C HIC M
C305	0.1	16	C C HIC M
C401	100	25	D R M VR
C404	100	25	D R M VR
C405	0.1	50	C C HIC M
C406	0.1	50	C C HIC M
C408	0.1	16	C C HIC M
C601	0.00068	50	C C HIC 205
C602	0.00068	50	C C HIC 205
C603	0.00068	50	C C HIC 205
C604	0.00068	50	C C HIC 205
C605	0.001	50	C C HIC 205
C606	0.001	50	C C HIC 205
C607	0.001	50	C C HIC 205
C608	0.047	25	C C HIC M
C801	0.15	50	F R M
C802	0.022	50	F R M
C803	0.01	25	C C HIC M
C804	0.01	25	C C HIC M
C805	68	50	D R M VR
C806	0.15	50	F R M
C807	0.15	50	F R M
C808	0.15	50	F R M
C809	0.15	50	F R M
C810	0.15	50	F R M
C811	0.01	25	C C HIC M
C812	0.01	25	C C HIC M
C901	0.01	1K	C H M
C903	120	25	D R M
C905	1000P	2K	C P M Lxv
C906	4700	50	C C HIC M
C907	1000P	50	C C HIC M
C908	0.1	50	C C HIC M
C909	330	50	D R M Lxv
C911	220	25	D R M Lxv
C912	330	25	D R M Lxv
C913	470	16	D R M Lxv
C914	470	16	D R M Lxv
C915	120	16	D R M Lxv
C916	0.1	50	C C HIC M
C918	0.001	25	C C HIC M
C919	0.001	25	C C HIC M
C920	0.1	50	C C HIC M
C921	100	10	C C HIC M
C922	0.1	50	C C HIC M
C923	180	10	D R M VR
C924	0.1	50	C C HIC M

CONNECTORS

MARK	M0DEL	REMARK	
CN2	R2P3-VH-R	R M	
CN6	R57-238-XH-A	H M	
CN8	R028-VASK-N	H M	
CN9	R028-VASK-1	H M	
CN10	R028-VASK-1	H M	
CN11	0-353297-5	H M	
CN12	R2P3-VH	H M	
CN13	0-175487-5	H M	
CN14	1-353297-0	H M	
CN15	R068-VASK-N	H M	
CN16	0-175487-4	H M	
CN17	0-175487-1	H M	
CN18	1-75487-1	H M	
C801	0.15	50	F R M
C802	0.022</		

MODEL RAC-25NH4, RAC-35NH4, RAC-50NH4


MAIN P.W.B. Marking on P.W.B



COMPONENT SIDE

BLOCK DIAGRAM

MODEL RAK-25NH4 / RAC-25NH4
 RAK-35NH4 / RAC-35NH4
 RAK-50NH4 / RAC-50NH4



BASIC MODE


MODEL RAK-25NH4, RAK-35NH4, RAK-50NH4

Operation mode	Fan	Cooling	Dehumidifying (dehumidifying operation by the function select button only, not including that engaged by the dehumidify button)	Heating	N&F auto	Special auto (not normally used)																
Basic operation of start/stop switch																						
Timer functions	Off-timer																					
	On-timer																					
	Off -> On On -> Off timer																					
Fan speed mode (indoor fan)	Auto	<p>Changes from "Hi" to "Med" or "Lo" depending on room temperature.</p> <p>1. Runs at "Hi" until first thermo off after operation is started. 2. Runs at "Lo" when thermo is off.</p>	<p>Changes between "Lo" and "Med" depending on the room temperature.</p> <table border="1"> <thead> <tr> <th>Temperature division</th> <th>Fan speed</th> </tr> </thead> <tbody> <tr> <td>Division 1</td> <td>Lo</td> </tr> <tr> <td>Division 2</td> <td>Lo</td> </tr> <tr> <td>Division 3</td> <td>Med</td> </tr> <tr> <td>Division 4</td> <td>Med</td> </tr> </tbody> </table> <p>1. The indoor fan also stops when the compressor is in stop status.</p>	Temperature division	Fan speed	Division 1	Lo	Division 2	Lo	Division 3	Med	Division 4	Med	<p>Set to "ultra-Lo", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchange temperature. Set to "stop" if the room temperature is 18°C in the "ultra-Lo" mode other than during preheating (cooling is recovered at 18.33°C).</p> <p>When the compressor is running at maximum speed during hot dash or when recovered from defrosting. In modes other than left</p>	<p>The neuro & fuzzy control allows device to determine optimum operation mode and set temperature. However, during auto cooling, the new cool rhythm starts when the room temperature is less than the set temperature plus 0.66°C, after dash is finished.</p>	<p>The special auto mode is based on N&F auto, but the following is different:</p> <table border="1"> <thead> <tr> <th>Operation mode</th> <th>Mode change during operation</th> </tr> </thead> <tbody> <tr> <td>N&F auto</td> <td>Does not change as long as outdoor temperature or calendar data does not change greatly.</td> </tr> <tr> <td>Special auto</td> <td>The operation mode will be judged the same as at operation start every hour.</td> </tr> </tbody> </table> <p>The special auto operation mode is entered when operation is started in the following status:</p> <p><Start condition> Power is supplied while the tele-control signal is being input. (Operation starts automatically.)</p> <p><End condition> The remote control restores the normal operation mode.</p> <p>Note (1) Since there is no stored calendar data, N&F control is not determined. See Note (2) of N&F auto.</p>	Operation mode	Mode change during operation	N&F auto	Does not change as long as outdoor temperature or calendar data does not change greatly.	Special auto	The operation mode will be judged the same as at operation start every hour.
	Temperature division	Fan speed																				
	Division 1	Lo																				
	Division 2	Lo																				
Division 3	Med																					
Division 4	Med																					
Operation mode	Mode change during operation																					
N&F auto	Does not change as long as outdoor temperature or calendar data does not change greatly.																					
Special auto	The operation mode will be judged the same as at operation start every hour.																					
Hi	Operates at "Hi" regardless of the room temperature.	Set to "ultra-Hi" when the compressor runs at maximum speed, and to "Hi" in other modes.	Set to "Hi" in modes other than when the compressor stops.	Set to "ultra-Lo", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, and time. Set to "stop" if the room temperature is 18°C in the "ultra-Lo" mode other than during preheating (cooling is recovered at 18.33°C). Set to "ultra-Hi" when the compressor is running at maximum speed during hot dash or when recovered from defrosting.	<p>Notes:</p> <p>(1) The set temperature can be varied $\pm 3^\circ\text{C}$ using the temperature setting buttons ^ and v.</p> <p>(2) If operation is started by tele-control or by temporary switch in status where remote control has not been used after power was supplied, the operation mode will be as follows (since there is no stored calendar data):</p> <table border="1"> <thead> <tr> <th>Room temperature at operation start (°C)</th> <th>Set temperature</th> <th>Fan mode</th> </tr> </thead> <tbody> <tr> <td>Cooling</td> <td>Set temperature: 28°C</td> <td>Fan mode: Auto</td> </tr> <tr> <td>Dehumidifying</td> <td>Set temperature: Room temperature at operation start</td> <td>Fan mode: Auto</td> </tr> <tr> <td>Heating</td> <td>Set temperature: 22°C</td> <td>Fan mode: Auto</td> </tr> </tbody> </table>	Room temperature at operation start (°C)	Set temperature	Fan mode	Cooling	Set temperature: 28°C	Fan mode: Auto	Dehumidifying	Set temperature: Room temperature at operation start	Fan mode: Auto	Heating	Set temperature: 22°C	Fan mode: Auto					
Room temperature at operation start (°C)	Set temperature	Fan mode																				
Cooling	Set temperature: 28°C	Fan mode: Auto																				
Dehumidifying	Set temperature: Room temperature at operation start	Fan mode: Auto																				
Heating	Set temperature: 22°C	Fan mode: Auto																				
Med	Operates at "Med" regardless of the room temperature.	Same as at left.	Set to "Med" in modes other than when the compressor stops.	Set to "ultra-Lo", "Lo", "Med" or "stop" depending on the room temperature and time. Set to "stop" if the room temperature is 18°C in the "ultra-Lo" mode other than during preheating (cooling is recovered at 18.33°C).																		
Lo	Operates at "Lo" regardless of the room temperature.	Same as at left.	Set to "Lo" in modes other than when the compressor stops.	Set to "ultra-Lo", "Lo", or "stop" depending on the room temperature and time. Set to "stop" if the room temperature is 18°C in the "ultra-Lo" mode other than during preheating (cooling is recovered at 18.33°C). The fan speed is controlled by the heat exchanger temperature; the overload control is executed as in the following diagram:																		
Basic operation of temperature controller	<p>Performs only fan operation at the set speed regardless of the room temperature.</p>	See page 49.	See page 53.	See page 55.																		
Sleep operation (with sleep button ON)	<ul style="list-style-type: none"> Enters sleep operation after set as on the left. Action during sleep operation Lo (sleep) operation 	<ul style="list-style-type: none"> Same as at left See page 51. 	<ul style="list-style-type: none"> Same as at left See page 53. 	<ul style="list-style-type: none"> Same as at left See page 57. 	<ul style="list-style-type: none"> Same as at left. Performs the sleep operation of each operation mode. 																	

Table 1 Mode data file

	RAK-25NH4	RAK-35NH4	RAK-50NH4
LABEL NAME	VALUE		
WMAX	4500 min ⁻¹	5500 min ⁻¹	6200 min ⁻¹
WMAX2	4600 min ⁻¹	5600 min ⁻¹	6250 min ⁻¹
WSTD	3250 min ⁻¹	4350 min ⁻¹	5200 min ⁻¹
WBEMAX	2600 min ⁻¹	2800 min ⁻¹	2600 min ⁻¹
CMAX	2900 min ⁻¹	3700 min ⁻¹	5700 min ⁻¹
CMAX2	3000 min ⁻¹	3800 min ⁻¹	5800 min ⁻¹
CSTD	2500 min ⁻¹	3550 min ⁻¹	5200 min ⁻¹
CKYMAX	2200 min ⁻¹	2800 min ⁻¹	3550 min ⁻¹
CJKMAX	2000 min ⁻¹	2500 min ⁻¹	2700 min ⁻¹
CBEMAX	1800 min ⁻¹	2200 min ⁻¹	2000 min ⁻¹
WMIN	1200 min ⁻¹	1200 min ⁻¹	1200 min ⁻¹
CMIN	1500 min ⁻¹	1500 min ⁻¹	1500 min ⁻¹
STARTMC	60 Seconds	60 Seconds	60 Seconds
DWNRATEW	80%	80%	80%
DWNRATEC	80%	80%	80%
SHIFTW	3.33°C	3.33°C	3.33°C
SHIFTC	1.00°C	1.00°C	0.33°C
CLMXTP	30.00°C	30.00°C	30.00°C
YNEOF	22.00°C	22.00°C	28.00°C
TEION	5.00°C	5.00°C	2.00°C
TEIOF	9.00°C	9.00°C	9.00°C
SFTDSW	1.00°C	1.00°C	1.00°C
DFTIM1	45 Minutes	45 Minutes	45 Minutes
DFTIM2	60 Minutes	60 Minutes	60 Minutes

Basic Cooling Operation



Notes:

- (1) Condition for entering into Cool Dashed mode. When fan set to "Hi" or "Auto mode" and temperature difference between indoor temperature and set temperature has a corresponding compressor rpm (calculated value in Table 7) larger than WMAX.
- (2) Cool Dashed will release when i) a maximum 25 minutes is lapsed and ii) room temperature is lower than set temperature -3°C (thermo off) and iii) when room temperature has achieved setting temperature -1°C then maximum Cool Dashed time will be revised to 20 minutes. And iv) indoor fan is set to Lo and Med fan mode and v) change operation mode.
- (3) During Cool Dashed operation, thermo off temperature is set temperature (with shift value) -3°C . After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum "ON" time and "OFF" time is 3 minutes.
- (5) During normal cooling mode, compressor maximum rpm CMAX will maintain for 60 minutes if indoor temperature is lower than CLMXTTP. No time constrain if indoor temperature is higher than CLMXTTP.
- (6) When fan is set to "Hi", compressor rpm will be limited to CKYMAX.
- (7) When fan is set to "Med", compressor rpm will be limited to CJKMAX.
- (8) When fan is set to "Lo", compressor rpm will be limited to CBEMAX.
- (9) During Cool Dashed, when room temperature reaches set temperature -1°C compressor rpm is actual rpm x DWNRATEC.


Table 2 ΔTCMAX

Temperature difference	Calculated compressor rpm
1.66	2265 min^{-1}
2	2435 min^{-1}
2.33	2600 min^{-1}
2.66	2765 min^{-1}
3	2935 min^{-1}
3.33	3100 min^{-1}
3.66	3265 min^{-1}
4	3435 min^{-1}
4.33	3600 min^{-1}
4.66	3765 min^{-1}
5	3935 min^{-1}
5.33	4100 min^{-1}
5.66	4265 min^{-1}
6	4435 min^{-1}
6.33	4600 min^{-1}
6.66	4765 min^{-1}
7	4935 min^{-1}
7.33	5100 min^{-1}
7.66	5265 min^{-1}
8	5435 min^{-1}
8.33	5600 min^{-1}
8.66	5765 min^{-1}
9	5935 min^{-1}
9.33	6100 min^{-1}
9.66	6265 min^{-1}
10	6435 min^{-1}
10.33	6600 min^{-1}
10.66	6765 min^{-1}
11	6935 min^{-1}

Note:

1. See the data in Table 1 on page 47 for each constant in capital letters in the diagrams.


New Cool Rhythm



Notes:

- (1) New cool rhythm is engaged when the fan speed is "auto" and the room temperature is less than set one plus 0.66°C in the "auto" operation mode or cooling mode.
- (2) The minimum new cool rhythm time is 10 minutes when the temperature falls and rises.
- (3) Cool rhythm is not engaged during Nice temperature, Sleep operation.
- (4) PI control is engaged during new cool rhythm: the speed limit is the same as during normal operation.
- (5) The new cool rhythm set temperature is also shifted during thermo OFF.


Cooling Sleep Operation




Notes:

- (1) The sleep operation starts when the sleep key is pressed.
- (2) When the sleep key is set, the maximum compressor speed is limited, and the indoor fan is set to "sleep Lo".
- (3) 30 minutes after the sleep key is set, the sleep shift of temperature starts, and upper shift is made at least 6 times. If 25°C is not reached after 6 shifts, shifts repeat unit 25°C is reached.
- (4) The sleep shift upper value of set temperature is 28°C.
- (5) After 6 hours, a shift down to the initial set temperature is made at a rate of 0.33°C/5 min.
- (6) If the operation mode is changed during sleep operation, the set temperature is cleared, and shift starts from the point when switching is made.
- (7) The indoor fan speed does not change even when the fan speed mode is changed.
- (8) When operation is stopped during sleep operation, the set temperature when stopped, as well as the time, continue to be counted.
- (9) If the set lime is changed during sleep operation, all data including set temperature, time, etc. is cleared and restarted.
- (10) If sleep operation is canceled by the cancel key or sleep key, all data is cleared.

Cooling Defrost




Dehumidifying



Notes:

- (1) If the room temperature is (cooling preset temperature) - (1.33°C) or less after 30 seconds from starting the operation, the operation is done assuming as the preset temperature = (room temperature at the time) - (2°C).
- (2) The indoor fan is operated in the "Lo" mode. During thermo OFF indoor fan will be OFF for 5 minutes and ON for 1 minute.
- (3) When the operation is started by the thermostat turning ON, the start of the indoor fan is delayed 32 seconds after the start of compressor operation.
- (4) The compressor is operated forcedly for 3 minutes after operation is started.
- (5) The minimum ON time and OFF time of the compressor are 3 minutes.

Basic Heating Operation



Notes:

- (1) Condition for entering into Hot Dashed mode. When fan set to "Hi" or "Auto mode" and i) Indoor temperature is lower than 18°C, and ii) outdoor temperature is lower than 10°C, and iii) Temperature difference between indoor temperature and set temperature has a corresponding compressor rpm (calculated value in Table 3) larger than WMAX.
- (2) Hot Dashed will release when i) Room temperature has achieved the set temperature + SFTDSW. ii) Thermo off.
- (3) During Hot Dashed operation, thermo off temperature is set temperature (with shift value) +3°C. After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum "ON" time and "OFF" time is 3 minutes.
- (5) During normal heating mode, compressor maximum rpm WMAX will maintain for 120 minutes if indoor temperature is higher than 18°C. No time limit constrain if indoor temperature is lower than 18°C and outdoor temperature is lower than 2°C.
- (6) During Hotkeep or Defrost mode, indoor operation lamp will blink at interval of 3 seconds "ON" and 0.5 second "OFF".
- (7) When heating mode starts, it will enter into Hotkeep mode if indoor heat exchanger temperature is lower than YNEOF + 0.33°C.
- (8) When fan is set to "Med" or "Lo", compressor rpm will be limited to WBEMAX.
- (9) In "Ultra-Lo" fan mode, if indoor temperature is lower than 18°C, indoor fan will stop. If indoor temperature is higher than 18°C + 0.33°C, fan will continue in "Ultra-Lo" mode. During Hotkeep or Defrost mode, fan will continue in "Ultra-Lo" mode.
- (10) During Hot Dashed or outdoor temperature is lower than -5°C, compressor rpm is WMAX2.
- (11) During Hot Dashed, when room temperature reaches set temperature + SFTDSW compressor rpm is actual rpm x DWNRATEW.


Table 3 ΔTWMAX

Temperature difference	Calculated compressor rpm
1.66	1965 min ⁻¹
2	2135 min ⁻¹
2.33	2300 min ⁻¹
2.66	2465 min ⁻¹
3	2635 min ⁻¹
3.33	2800 min ⁻¹
3.66	2965 min ⁻¹
4	3135 min ⁻¹
4.33	3300 min ⁻¹
4.66	3465 min ⁻¹
5	3635 min ⁻¹
5.33	3800 min ⁻¹
5.66	3965 min ⁻¹
6	4135 min ⁻¹
6.33	4300 min ⁻¹
6.66	4465 min ⁻¹
7	4635 min ⁻¹
7.33	4800 min ⁻¹
7.66	4965 min ⁻¹
8	5135 min ⁻¹
8.33	5300 min ⁻¹
8.66	5465 min ⁻¹
9	5635 min ⁻¹
9.33	5800 min ⁻¹
9.66	5965 min ⁻¹
10	6135 min ⁻¹
10.33	6300 min ⁻¹
10.66	6465 min ⁻¹
11	6635 min ⁻¹

Notes:

1. See the data in Table 1 on page 47 for each constant in capital letters in the diagrams.


Reversing Valve Defrosting



Notes:

- (1) The defrosting inhibit period is set as shown in the diagram below. When defrosting has finished once, the inhibit period is newly set, based on the outdoor temperature when the compressor was started. During this period, the defrost signal is not accepted.
- (2) If the difference between the room and outdoor temperature is large when defrosting is finished, the maximum compressor speed (WMAX) or (WMAX2) can be continued for 120 minutes maximum.
- (3) The defrosting period is 12 minutes maximum.
- (4) When operation is stopped during defrosting, it is switched to auto refresh defrosting.
- (5) Auto refresh defrosting cannot be engaged within 15 minutes after operation is started or defrosting is finished.


Setting Defrosting Inhibit Period



Notes:

- (1) The time is set according to the outdoor temperature when it is between 0°C and -5°C.
- (2) DFTIM1 is used when the outdoor temperature $\geq 0^\circ\text{C}$.
- (3) DFTIM2 is used when the outdoor temperature $\leq -5^\circ\text{C}$.

Heating Sleep Operation



Notes:

- (1) The sleep operation starts when the sleep key is pressed.
- (2) When the sleep key is set, the maximum compressor speed is limited to WSTD+2000/2, and the indoor fan is set to "sleep Lo".
- (3) 30 minutes after the sleep key is set, the sleep shift of set temperature starts.
- (4) The maximum sleep shift of set temperature is 5°C, and the minimum is 12°C.
- (5) If the operation mode is changed during sleep operation, the changed operation mode is set and sleep control starts.
- (6) The indoor fan speed does not change even when the fan speed mode is changed. (Lo)
- (7) When defrosting is to be set during sleep operation, defrosting is engaged and sleep operation is restored after defrosting.
- (8) When operation is stopped during sleep operation, the set temperature when stopped, as well as the time, continue to be counted.
- (9) If the set time is changed during sleep operation, all data including set temperature, time, etc. is cleared and restarted.
- (10) If sleep operation is canceled by the cancel key or sleep key, all data is cleared.


REFRIGERATING CYCLE DIAGRAM

MODEL RAK-25NH4 / RAC-25NH4

RAK-35NH4 / RAC-35NH4


COOLING, DEHUMIDIFYING, DEFROSTING

OUTDOOR UNIT



HEATING


OUTDOOR UNIT




REFRIGERATING CYCLE DIAGRAM

MODEL RAK-50NH4 / RAC-50NH4

COOLING, DEHUMIDIFYING, DEFROSTING



HEATING



AUTO SWING FUNCTION

MODEL: RAK-25NH4, RAK-35NH4, RAK-50NH4

INPUT SIGNAL	PRESENT CONDITION			OPERATING SPECIFICATION	REFERENCE
	OPERATION	OPERATION MODE	AIR DEFLECTOR		
KEY INPUT	STOP	EACH MODE	STOP	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			DURING ONE SWING	STOP AT THE MOMENT.	
	DURING OPERATION	AUTO COOL COOL FAN AUTO DRY DRY	STOP	START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD	
			DURING SWINGING	STOP AT THE MOMENT.	
		AUTO HEAT HEAT CIRCULATOR	STOP	START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD	
			DURING SWINGING	STOP AT THE MOMENT.	
THERMO. ON (INTERNAL FAN ON)	DURING OPERATION	AUTO DRY DRY AUTO HAET HEAT CIRCULATOR	TEMPORARY STOP	START SWING AGAIN.	
THERMO. ON (INTERNAL FAN OFF)			DURING SWINGING	STOP SWINGING TEMPORARILY. (SWING MODE IS CLEARED IF SWING COMMAND IS TRANSMITTED DURING TEMPORARY STOP.)	
MAIN SWITCH ON	STOP	COOL FAN DRY	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD ② UPWARD	
		HEAT CIRCULATOR	STOP DURING ONE SWING	INITIALIZE ① DOWNWARD	
MAIN SWITCH OFF	DURING OPERATION	EACH MODE	STOP DURING SWINGING	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			DURING INITIALIZING		
CHANGE OF OPERATION	DURING OPERATION	EACH MODE	STOP	INITIALIZING CONDITION OF EACH MODE.	
			DURING SWINGING	STOP SWINGING AND MODE BECOMES INITIALIZING CONDITION.	

DESCRIPTION OF MAIN CIRCUIT OPERATION

MODEL RAK-25NH4, RAK-35NH4, RAK-50NH4

1. Reset Circuit




Fig. 1-1




Fig. 1-2

- The reset circuit initializes the microcomputer program when power is ON or OFF.
- Low voltage at pin 7 resets the microcomputer and Hi activates the microcomputer.
- When power "ON" 5V voltage rises and reaches 4.4V, pin 1 of IC521 is set to "Hi". At this time the microcomputer starts operation.
- When power "OFF" voltage drops and reaches 4.2V, pin 1 of IC521 is set to "Low". This will RESET the microcomputer.

2. Receiver Circuit




Fig. 2-1

- The light receiver unit receives the infrared signal from the wireless remote control. The receiver amplifies and shapes the signal and outputs it.

3. Buzzer Circuit




Fig. 3-1 Buzzer Circuit

- When the buzzer sounds, an approx. 3.9kHz square signal is output from buzzer output pin (30) of the microcomputer. After the amplitude of this signal has been set to 12Vp-p by a transistor, it is applied to the buzzer. The piezoelectric element in the buzzer oscillates to generate the buzzer's sound.




Fig. 3-2 Buzzer Operation

4. Auto Sweep Motor Circuit




Fig.4-1

- Fig. 4-1 shows the Auto sweep motor drive circuit; the signals shown in Fig.4-2 are output from pins 15 – 18 of microcomputer.

Microcomputer pins	Step width								Horizontal air deflectors: 10ms.
Horizontal air deflectors	1	2	3	4	5	6	7	8	
15	High	High	High	High	Low	Low	Low	Low	
16	High	Low	Low	Low	Low	Low	High	High	
17	Low	Low	Low	Low	High	High	High	High	
18	Low	Low	High	High	High	High	Low	Low	

Fig.4-2 Microcomputer Output Signals

- As the microcomputer's outputs change as shown in Fig.4-2, the core of the auto sweep motor is excited to turn the rotor. Table 4-1 shows the rotation of horizontal air deflectors.

Table 4-1 Auto sweep Motor Rotation

	Rotation angle per step (°)	Time per step (ms.)
Horizontal air deflectors	0.0882	10

5. Room Temperature Thermistor Circuit

- Fig. 5-1 shows the room temperature thermistor circuit.




Fig. 5-1

- The voltage at (A) depends on the room temperature as shown in Fig. 5-2.




Fig. 5-2

6. Heat exchanger temperature thermistor circuit




Fig. 6-1

- The circuit detects the indoor heat exchanger temperature and controls the following.

- (1) Preheating.
- (2) Low-temperature defrosting during cooling and dehumidifying operation.
- (3) Detection of the reversing valve non-operation or heat exchanger temperature thermistor open.

The voltage at (A) depends on the heat exchanger temperature as shown in Fig. 6-2.




Fig. 6-2

7. Initial Setting Circuit (IC401)

- When power is supplied, the microcomputer reads the data in IC401 or IC402 (E²PROM) and sets the preheating activation value and the rating and maximum speed of the compressor, etc. to their initial values.
- Data of self-diagnosis mode is stored in IC401 or IC402; data will not be erased even when power is turned off.




Fig. 7-1

Model RAC-25NH4, RAC-35NH4, RAC-50NH4

1. Power Circuit




Fig. 1-1

- This circuit full-wave rectifies 220-230V AC applied between terminals L and N, and boosts it to a required voltage with the active module, to create a DC voltage.

The voltage becomes 260-360V when the compressor is operated

(1) Active module

The active filter, consisting of a reactor and switching element, eliminates higher harmonic components contained in the current generated when the compressor is operated, and improves the power-factor.

(2) Diode stacks

These rectify the 220-230V AC from terminals L and N to a DC power supply.

< Reference >

- In case of malfunction or defective connection: Immediately after the compressor starts, it may stop due to "abnormally low speed" active error, etc.

The compressor may continue to operate normally, but the power-factor will decrease, the operation current will increase, and the overcurrent breaker of the household power board will probably activate.

- In case of active module faulty or defective connection:

Although the compressor continues to operate normally, the power-factor will decrease, the operation current will increase, and the overcurrent breaker of the household power board will probably activate.

< Reference >

- If diode stack 1 is faulty, the compressor may stop due to "Ip", "abnormally low speed", etc. immediately after it starts, or it may not operate at all because no DC voltage is generated between the positive ⊕ and negative ⊖ terminals.

If diode stack 1 is faulty, be aware that the 25A fuse might also have blown.

- If diode stack 2 is faulty, DC voltage may not be generated and the compressor may not operate at all. Also, be aware that the 3A fuse might have blown.

(3) Smoothing capacitor (C501, C502, C503)

This smoothes (averages) the voltage rectified by the diode stacks.

<Notes> Smoothing capacitor C501 is not available for model RAC-25NH4 and RAC-35NH4.




Fig. 1-2




Fig. 1-3

- Be careful to avoid an electric shock as a high voltage is generated. Also take care not to cause a short-circuit through incorrect connection of test equipment terminals. The circuit board could be damaged.

(4) Smoothing capacitor (C010, C011)

This smoothes (averages) the voltage rectified by the diode stack. A DC voltage is generated in the same way as in Fig. 1-3.

Voltage between + side of C010 and - side of C011 is about 330V.

(5) C001 to C003, C012 to C015, C007, C008, NF COIL1, COIL, absorb electrical noise generated during operation of compressor, and also absorb external noise entering from power line to protect electronic parts.

(6) Surge absorber, Varistor 1, 2, 3, absorbs external power surge.

(7) Inrush protective resistor (R007, R008)

This works to protect from overcurrent when power is turned on.

< Reference >

- When inrush protective resistor is defective, diode stack may malfunction. As a result, DC voltage is not generated and no operation can be done.

2. Indoor/Outdoor Interface Circuit

- The interface circuit superimposes an interface signal on the DC 35V line supplied from the outdoor unit to perform communications between indoor and outdoor units. This circuit consists of a transmitting circuit which superimposes an interface signal transmit from the microcomputer on the DC 35V line and a transmitting circuit which detects the interface signal on the DC 35V line and outputs it to the microcomputer.
- Communications are performed by mutually transmitting and receiving the 4-frame outdoor request signal one frame of which consists of a leader of approx. 100 ms., start bit, 8-bit data and stop bit and the command signal with the same format transmit from the indoor unit.
- Communication signal from outdoor microcomputer to indoor microcomputer. At first outdoor microcomputer will send a request signal (SDO) to indoor microcomputer. A high-frequency IF signal approx. 38 KHz is generated and modulated by the request signal (SDO) inside the outdoor microcomputer then output to pin (11) of microcomputer. This modulated IF signal is output to pin (30) of HIC and amplified by amp. This signal is superimposed to DC 35V line via C801 and L801.
To prevent erroneous reception, the outdoor microcomputer is designed so that it cannot receive a signal while it is outputting a request signal.
The receiving circuit in the indoor unit consists of a comparator and transistor. The interface signal from the outdoor unit on the DC 35V line is supplied to C821, where DC components are eliminated, and is then shaped by the comparator. The shaped signal is detected by diode, amplified by amp, and output to pin (49) of the indoor microcomputer.
Fig. 2-2 shows the voltages at each component when data is transferred from the outdoor microcomputer to the indoor microcomputer.
- Communication signal from indoor microcomputer to outdoor microcomputer. The request signal (SDO) generates by indoor microcomputer is output to pin (50), and amplifies by C801. IF signal approx. 38 kHz is generated by comparator, then modulate by the request signal from pin (50) of indoor microprocessor. This modulated IF signal is then amplified and superimposed to DC 35V line via L801 and C802 of indoor interface circuit.
Fig. 2-3 shows the voltages at each component when data is transferred from outdoor microcomputer to indoor microcomputer.
The circuit operation of the outdoor receiving circuit is same as indoor receiving circuit.

- Fig. 2-1 shows the interface circuit used for the indoor and outdoor microcomputers to communicate with each other.




Fig. 2-1 Indoor/outdoor interface Circuit




Fig. 2-2 Voltages Waveforms of indoor / Outdoor Microcomputers (Outdoor to Indoor Communications)






Fig. 2-3 Voltages Waveforms of indoor / Outdoor Microcomputers (Indoor to Outdoor Communications)

[Serial Communications Format during Normal Communications]

(1) Outdoor microcomputer (HIC) to indoor microcomputer



(2) Indoor microcomputer to outdoor microcomputer (HIC)



(3) Communications waveforms

[Example] When the outdoor message is all 0s and indoor message is all 1s:




Fig. 2-4

[Serial Communications Data]

(1) Outdoor message

Character No.	0							1							2							3										
Bit No.	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
Contents	Multi-bit		During forced operation	Defrost request signal	Self-diagnosis (0 LSB)	Self-diagnosis (1)	Self-diagnosis (2)	Self-diagnosis (3 MSB)	Outside temperature (0 LSB)	Outside temperature (1)	Outside temperature (2)	Outside temperature (3)	Outside temperature (4)	Outside temperature (5)	Outside temperature (6)	Outside temperature (7 MSB)	Compressor during operation	Compressor during operation	Actual compressor rotation speed (0 LSB)	Actual compressor rotation speed (1)	Actual compressor rotation speed (2)	Actual compressor rotation speed (3)	Actual compressor rotation speed (4)	Actual compressor rotation speed (5 MSB)		Fan-7-step request						
Data	1/0	0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	0	1	0	0	0	0	0	0

(2) Indoor message

Character No.	0							1							2							3										
Bit No.	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
Contents	Operation mode (0 LSB)	Operation mode (1)	Operation mode (2 MSB)	Indoor in-operation bit	Capacity code (0 LSB)	Capacity code (1)	Capacity code (2)	Capacity code (3 MSB)	Fan (0 LSB)	Fan (1)	Fan (2 MSB)	2-way valve	Reversing valve			Compressor ON	Compressor command speed (0 LSB)	Compressor command speed (1)	Compressor command speed (2)	Compressor command speed (3)	Compressor command speed (4)	Compressor command speed (5)	Compressor command speed (6)	Compressor command speed (7 MSB)	15/20(A)	OVL up						
Data	1/0	1/0	1/0	1/0	0	0	0	0	1/0	1/0	1/0	0	1/0	0	0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	1/0	

- Fig. 3-1 shows the system power module and its peripheral circuit. The three transistors on the positive \oplus side are called the upper arm, and the three transistors on the negative \ominus side, the lower arm.




Fig. 3-1 Power module circuit (U^+ is ON, V^- is ON)

- DC 260-360V is input to system power module and system power module switches power supply current according to rotation position of magnet rotor. The switching order is as shown in Fig. 3-2.




Fig. 3-2 Switching order of power module

- Upper arm transistor is controlled to ON/OFF by 3.3kHz chopper signal. Rotation speed of the compress is proportional to duty ratio (ON time/ ON time + OFF time) of this chopper signal.
- Time T in Fig. 3-2 shows the switching period, and relation with rotation speed (N) of the compressor is shown by formula below;

$$N = 60/2 \times 1/T$$

- Fig. 3-3 shows voltage waveform at each point shown in Figs. 3-1 and 3-4. First half of upper arm is chopper, second half is ON, and first half of lower arm is chopper, second half is ON.




Fig. 3-3 Voltage waveform at each point

- When power is supplied U⁺ → U⁻, because of that U⁺ is chopped, current flows as shown below; (B)
 - (1) When U⁺ transistor is ON: U⁺ transistor → U coil → V coil → V⁻ transistor → DC current detection resistor → Point (B) (Fig. 3-1)
 - (2) When U⁺ transistor is OFF: (by inductance of motor coil) U coil → V coil → V⁻ transistor → Return diode → Point (A) (Fig. 3-4)




Fig. 3-4 Power module circuit (U⁺ is ON, V⁻ is ON)

- Since current flows at point ② only when U⁺ transistor is ON, the current waveform at point ② becomes intermittent waveform as shown in Fig. 3-3. Since current at point ② is approximately proportional to the input current of the air conditioner, input current is controlled by using DC current (I_d) detection resistor.

<Reference>

If power module is defective, self diagnosis lamps on the control P.W.B. may indicate as shown below:




Fig. 3-5

Table 3-1

Self-diagnosis	Self-diagnosis lamp and mode	
I _p (peak current cut)	LD301	Blinks 2 times
Abnormal low speed rotation	LD301	Blinks 3 times
Switching incomplete	LD301	Blinks 4 times

- Simplified check of power module (Lighting mode when operated with compressor leads disconnected)
 - (1) Disconnect connector of 3-pole (WHT, YEL, RED) lead wire connecting to compressor located at the lower part of electric parts box.
 - (2) Set to compressor operation state (other than FAN mode) and press Start/stop switch of remote control.
 - (3) If normal operation continues for more than 1 minute (LD303 lights), power module is considered normal.
- * Refer to other item (troubleshooting on page 94) for independent checking of power module.

4. Power Circuit for P.W.B.

- Fig. 4-1 shows the power circuit for P.W.B. and waveform at each point.




Fig. 4-1 Power circuit for P.W.B.

- In the power circuit for P.W.B., power supply for microcomputer, peripheral circuits, and system power module driver circuit and, as well as DC 35V, are produced by switching power circuit.
- Switching power circuit performs voltage conversion effectively by switching transistor IC901 to convert DC 330V voltage to high frequency of about 20kHz to 200kHz.
- Transistor IC901 operates as follows:

(1) Shifting from OFF to ON

- DC about 330V is applied from smoothing capacitors C010 ⊕ and C011 ⊖ in the control power circuit. With this power, current flows to pin ④ of IC901 via R903 and R904 and IC901 starts to turn ON. Since voltage in the direction of arrow generates at point ③ at the same time, current passing through R910 and D903 is positive-fed back to IC901.

(2) During ON

- The drain current at IC901 increases linearly. During this period, the gate voltage and current become constant because of the saturation characteristics of the transformer.

(3) Shifting from ON to OFF

- This circuit applies a negative feedback signal from the 12V output. When the voltage across C919 reaches the specified value, REG2 turns on and current flows to PQ2 ①-②. This turns the secondary circuits on, sets IC901 pin ① to "Hi", and turns IC901 off.

(4) During OFF

- While IC901 is on, the following energy charges the primary windings of the transformer:

Energy= $LI^2/2$. Here, L : Primary inductance

I : Current when IC1 is off

This energy discharges to the secondary windings during power off. That is, C910, C911, C912, C914 is charged according to the turn ratio of each winding.

- At the start, an overcurrent flows to IC901 because of the charged current at C910, C911, C912, C914.
- The drain current at IC901 generates a voltage across R906. If it exceeds the IC901 base voltage, it sets the IC901 gate voltage to "Hi".
- R906 limits the gate voltage to prevent excessive collector current from flowing to IC901.

<Reference>

If the power circuit for P.W.B. seems to be faulty:

- (1) Make sure that 5V and 12V on the control P.W.B., upper arm U, V and W, and the lower arm power voltage are the specified values.

- (2) When only the 5V output is low:

REG 1 (regulator) faulty, 5V-0V shorted, output is too high, or REG 1 is abnormal.

- (3) When 12V and 5V are abnormal:

The following defects can be considered:

① Fan, operation, power, rush prevention relay (shorting in relay, etc.)

② Microcomputer is abnormal.

③ REG 1 (regulator is abnormal), etc.

Shorting on primary circuits.

When shorting occurs in the secondary circuits, there is no abnormality in the primary circuits because of overcurrent protection.

The voltage rises when an opening occurs in the primary circuits, or the feedback system is abnormal.

- (4) When 15V and 17V are abnormal:

D908, D909 or drive circuit is abnormal.

- (5) When all voltage are abnormal:

IC901, R906, etc. are possibly abnormal.

* If IC901 is abnormal, be aware that other components, such as the power module, REG (regulator), etc. are possibly defective.

[When the switching power supply seems to be abnormal, the voltage between IC901 pin ④ (to be measured at the leads of R904 and R903) and IC901 pin ⑤ (to be measured at R906 lead) may be between 11 and 16V. This is because the protection circuit of IC901 is operating.]

5. Reversing valve control circuit




Fig. 5 - 1

- Reversing valve control circuit can switch reversing valve ON/OFF according to instruction from indoor microcomputer depending on the operation condition shows in Table 5-1. Voltage at each point in each operation condition is approximately as shown below when measured by tester. (When collector voltage of Q701 is measured)

Table 5-1

Operation condition		Collector voltage of Q701
Cooling	General operation of Cooling	About 35V
Heating	In normal heating operation	About 0.8V
	MAX. rotation speed instructed by indoor microcomputer after defrost is completed	About 0.8V
	Defrosting	About 35V
Dehumidifying	Sensor dry	About 35V

6. Rotor magnetic pole position detection circuit





Fig. 6-1 Rotor magnetic pole position detection circuit and voltage waveform at each point

- To detect U phase, voltage at point © is produced by driving motor induced voltage signal (voltage at point (A)) and 1/2 voltage of V_d (voltage at point (B)), and comparing with comparator.
- For V phase and W phase, voltage at point (D) and voltage at point (E) are produced in the same way as above. Voltage at point © is taken into indoor unit microcomputer, switching timing to U^+ transistor from W^+ transistor is produced by delaying 30° from rise waveform, ignoring spike voltage. In addition, switching timing to U-transistor from W-transistor is produced by delaying 30° from fall waveform.
- For V phase and W phase, in the same way as above, drive signals are produced from voltages at point (D) and point (E). Phases are shifted by 120° and 240° , respectively, comparing with U phase.

7. Drive Circuit

Fig. 7-1 shows the drive circuit. The circuits for U phase, V phase and W phase have the same Configuration.

- In low speed rotation mode (PWM range), as shown in Fig. 7-2, 0-5V chopper signal is output from microcomputer for each phase. Signal output from microcomputer is output to IC1 and is inverted by active Lo to become 0-15V chopper signal; it is then drive the transistor of each phase.
- In high speed rotation mode (PWM range), as shown in Fig. 7-3, 0-5V drive signal is output from microcomputer for each phase (with no chopper because of full duty). Signal output from microcomputer is input to IC1 and is inverted by active Lo to become 0-15V drive signal; it is then drive the transistor of each phase.




Fig.. 7-1

[Low speed rotation mode]




Fig. 7-2

[High speed rotation mode]




Fig. 7-3

8. HIC and Peripheral Circuits

- Fig. 8-1 shows the micro computer and its peripheral circuits, Table 8-1, the basic operations of each circuit block, and Fig. 8-2, the system configuration.




Fig. 8-1 Microcomputer and Peripheral Circuits

Table 8-1

Circuit block	Basic operation
Peak current cutoff circuit	Detects DC current flowing power module and during overcurrent (instantaneous value) flows, stops upper/lower arm drive circuits and also produces I_p signal by which drive signal output is stopped.
Set value circuit	Compares voltage detected, amplified and input to HIC with set voltage value in microcomputer, and controls overload when set value exceeds input voltage.
Voltage amplifier circuit	Voltage-amplifies DC current level detected by the detection resistor and inputs this to microcomputer. Internal or external overload is judged in microcomputer.
Reset circuit	Produces reset voltage.
Trip signal synthesis circuit	Modulates chopper signal to drive signal and stops according to presence/absence of I_p signal or reset signal.




Fig. 8-2

- The following describes the operations of each circuit in detail.

(1) Peak current cut off circuit

Fig.8-3 Peak Current Cut off Circuit and Waveforms at Each Section.




Fig.8-3

- The Ip cut off circuit detects an instantaneous excessive current and stops inverter to protect parts such as SPM2, etc.
- As shown in diagram, if current exceeding 21A (27A for RAC-50NH4) flows, voltage at point (A) recognized by detecting resistor is input to pin (10) of SPM2 – HIC, and voltage divided by R41 and R43 is input to pin (9) of IC1. Since threshold of IC1 is exceeded in this case, Lo signal is input from pin (8) (Voltage at point (B)). When Lo signal is input to pin (17) of microcomputer, microcomputer stops drive output.
- When drive output from microcomputer is stopped, all drive output goes Hi, and microcomputer is initialized to enter drive signal standby mode. 3 minutes later, microcomputer outputs drive signal again, to start operation.

(2) Overload control circuit (OVL control circuit)

- Overload control is to decrease the speed of the compressor and reduce the load when the load on the air conditioner increases to an overload state, in order to protect the compressor, electronic components and power breaker.
- Overloads are judged by comparing the DC current level and set value.
- Fig. 8-4 shows the overload control system configuration and Fig. 8-5 is a characteristic diagram of overload judgement values. There are two judgement methods-external judgement which compares the externally set value with the DC current value regardless of the rotation speed and internal judgement which compares the set value that varies according to the rotation speed programmed in the microcomputer software with the DC current value.




Fig. 8-4 Overload Control System Configuration




Fig. 8-5

①. Overload external judgement circuit

- Fig. 8-1. The filter consisting of R245 and C217 removes high harmonic components from the voltage generated by the current flowing to Detection resistor; R245 and C217 average the voltage. This voltage is then input to IC4 pin ⑤ is then amplified and supplied to microcomputer pin ⑩. The microcomputer compares this input with the internally set value, and if the input exceeds the set value, it enters overload control status.
- Fig. 8-7 shows the rotation speed control. When the voltage at pin ⑩ of the microcomputer exceeds the set value, the microcomputer decreases the rotation speed of the compressor and reduces the load regardless of the rotation speed commanded by the indoor microcomputer.




Fig. 8-6




Fig. 8-7

②. Voltage amp. circuit

- The voltage amp. circuit amplifies the DC current level detected by the detection resistor after being converted to a voltage and supplies it to the microcomputer. Receiving this, the microcomputer converts it to a digital signal and compares it with the internal data to judge whether or not overload control is required.

< During overload control >

- The filter consisting of R245 and C217 removes high harmonic components from the voltage generated from the DC current flowing to the detection resistor, and supplies it to IC4 pin ⑤ IC4 forms a non-inverting voltage amp. circuit together with the peripheral elements.
- The microcomputer stores the set values which vary according to the rotation speed. When the DC current level exceeds the set value, the microcomputer enters the overload control state.
- The set Value is determined by the amplification of the voltage amp. circuit.

- Amplification : high → DC current : low
- Amplification : low → DC current : high

- R500, R253, detect the DC voltage at the power circuit. The microcomputer receives a DC voltage (260-380V) via HIC ③7 and applies correction to the overload set value so the DC current is low (high) when the DC voltage is high (low).

(Since the load level is indicated by the DC voltage multiplied by DC current, R247, R248, R249 are provided to perform the same overload judgement even when the voltage varies.)




Fig. 8-8

< During start current control >

- It is required to maintain the start current (DC current) constant to smooth the start of the DC motor for the compressor.
- RAC-25NH4, RAC-35NH4, RAC-50NH4 uses software to control the start current.
- The start current varies when the supply voltage varies. This control method copes with variations in the voltages as follows.

(1) Turns on the power module's U⁺ and V⁻ transistors so the current flows to the motor windings as shown in Fig8-9.

(2) Varies the turn-ON time of the W⁺ transistor according to the DC voltage level and the start is controlled so the start current is approx. 10A as shown in Fig. 8-10.




Fig. 8-9




Fig. 8-10

9. Temperature Detection Circuit




Fig. 9-1

- The Over heat thermistor circuit detects the temperature at the surface of the compressor head, the Defrost. thermistor circuit detects the defrosting operation temperature.
- A thermistor is a negative resistor element which has the characteristics that the higher (lower) the temperature, the lower (higher) the resistance.
- When the compressor is heated, the resistance of the Over heat thermistor becomes low and voltage at pin ⑥② of microcomputer is increased.
- Microcomputer compares the voltage present at pin ⑥② with the internal set value, if it is exceeded the set value microcomputer judges that the compressor is overheated and stops operation.
- When frost forms on the outdoor heat exchanger, the temperature at the exchanger drops abruptly. Therefore the resistance of the Defrost. thermistor becomes high and the voltage at pin ⑥③ of microcomputer drops. If this voltage becomes lower than the set value stored inside, the microcomputer starts defrosting control.
- During defrosting operation the microcomputer transfers the defrosting condition command to the indoor microcomputer via the circuit interface.
- The microcomputer always reads the outdoor temperature via a thermistor (microcomputer pin ⑥④), and transfers it to the indoor unit, thus controlling the compressor rotation speed according to the value set at the EEPROM in the indoor unit, and switching the operation status (outdoor fan on/off, etc.) in the dry mode.

The following shows the typical values of outdoor temperature in relation to the voltage:

Table 9-1

Outdoor temperature (°C)	-10	0	10	20	30	40
Microcomputer pin ⑤ voltage (V)	1.19	1.69	2.23	2.75	3.22	3.62

<Reference>

When the thermistor is open, in open status, or is disconnected, microcomputer pins ⑥②–⑥④ are approx. 0V; when the thermistor is shorted, they are approx. 5 V, and LD301 blinks seven times.

However, an error is detected only when the OH thermistor is shorted; in such a case, the blinking mode is entered 12 minutes after the compressor starts operation.

10. Reset Circuit




Fig. 10-1

- The reset circuit initializes the microcomputer program when Power is "ON" or "OFF".
- Low voltage at pin 48 resets the microcomputer, and HI activates the microcomputer.
- Fig. 10-1 shows the reset circuit and Fig. 10-2 shows waveform at each point when power is turned on and off.
- When power is turned on, 12V line and 5V line voltages rise and 12V line voltage reaches 10.9V and reset voltage input to pin 48 of microcomputer is set to Hi.
- Reset voltage will be hold "Hi" until the 12V line voltage drops to 9.90V even though the power shuts down.




Fig. 10-2

11. Outdoor DC Fan Motor control circuit.




Fig. 11-1

- This model uses DC Fan Motor which has a controller circuit in the Motor.
- This DC Fan Motor will rotate by control voltage apply to Vsp input. (Voltage range: 1.7 to 7V DC)
Vsp high : Faster ; Vsp low : slower ; Vsp lower than 1.7V : stop
- Motor will output FG pulse by following this motor revolution.
- Outdoor Microprocessor will output PWM control signal from FMCHOP terminal by following the instruction from indoor Microprocessor.
- This PWM control signal will convert to Vsp voltage by smoothing circuit (Q101 & RC filter)
- Fan motor will start to rotate when Vsp was proceeding over than 1.7V, and generate FG pulse by rotation speed.
- FG pulse will feed back to Outdoor Microprocessor through PQ102.
- PQ102 is the isolator between Microprocessor circuit and DC Fan Motor circuit, which has to match the Fan Motor revolution with instructed revolution. Such as...
FG feedback: Faster – Instruction: Slower ... Decrease pulse width
FG feedback: Slower – Instruction: Faster ... Increase pulse width
- FG pulse is also used for Fan Motor failure detection
- Microprocessor will monitor FG pulse 30 seconds after start the fan motor. If there is no signal detected, it will consider that the Fan Motor was malfunction and stop the operation. In this case, LD302 on control PWB will blink 12 times. (Fan Motor lock detected)
- R107 and IC4 are used for Fan Motor over current

< Reference >

- When operation stop with LD301 blinks 12 times, it may be caused by faulty DC fan motor.
- In this case, please check CN6 and CN12 connection first. It makes Fan Motor Lock also if those connectors are in misconnection.
- DC Fan Motor has broken when 2A Fuse was burned. Please replace both DC Fan Motor and 2A Fuse together.
- It will makes "Fan Lock Stop" when something has disturb the Fan rotation by inserting materials into propeller fan or ice has growing inside of outdoor unit by snowing.
- It may make "Fan Lock Stop" by strong wind (ex. 17m/sec or above) against the Fan rotation. In this case, unit will be restart again after a while.
- In case of "Fan Lock Stop" even though the DC Fan Motor is rotating correctly, the possible casue is Fan Motor problem or PQ102 on board or control board problem. Stop after the Fan motor runs 2 minutes, Fan Motor may be broken.


< Caution >

- Please take care for the electrical shock by high voltage of DC Fan Motor power source which is common with compressor when you are servicing this unit.
- You can not confirm the coil and wiring of Motor due to the built in control circuit in Fan Motor.

12. Power Factor Control Circuit

Power factor is controlled to almost 100%. (Effective use of power)

With IC in ACT module, control is performed so that input current waveform will be similar to waveform of input voltage




(Even if voltage is applied, current does not flow)

* Assuming the same current capacity (20A), power can be used about 10% effective, comparing with current use (power factor of 90%), and maximum capacity is thereby improved.


SERVICE CALL Q & A

Model RAK-25NH4 / RAC-25NH4
RAK-35NH4 / RAC-35NH4
RAK-50NH4 / RAC-50NH4


COOLING MODE



DEHUMIDIFYING MODE



HEATING MODE



AUTO FRESH DEFROSTING

Q7) After the ON/OFF button is pressed to stop heating, the outdoor unit is still working with the OPERATION lamp lighting.



A7) Auto Fresh Defrosting is carried out : the system checks the outdoor heat exchanger and defrosts it as necessary before stopping operation.

AUTO OPERATION

Q8) Fan speed does not change when fan speed selector is changed during auto operation.



A8) At this point fan speed is automatic.

NICE TEMPERATURE RESERVATION

Q9) When on-timer has been programmed, operation starts before the preset time has been reached.



A9) This is because "Nice temperature reservation" function is operating. This function starts operation earlier so the preset temperature is reached at the preset time. Operation may start maximum 60 minutes before the preset time.

Q10) Does "Nice temperature reservation" function operate during dehumidifying?



A10) It does not work. It works only during cooling and heating.

Q11) Even if the same time is preset, the operation start time varies.



A11) This is because "Nice temperature reservation" function is operating. The start time varies according to the load of room. Since load varies greatly during heating, the operation start time is corrected, so it will vary each day.

INFRARED REMOTE CONTROL

Q12) Timer cannot be set.



A12) Has the clock been set? Timer cannot be set unless the clock has been set.

Q13) The current time display disappears soon.



A13) The current time disappears in approx. 10 seconds. The time set display has priority.

When the current time is set the display flashes for approx 3 minutes.

Q14) The timer has been programmed, but the preset time disappears.



A14) Is the current time past the preset time? When the preset time reaches the current time, it disappears.

OTHERS

Q15 The indoor fan varies among high air flow, low air flow and breeze in the auto fan speed mode. (Heating operation)



A15 This is because the cool wind prevention function is operating, and does not indicate a fault.

The heat exchanger temperature is sensed in the auto speed mode. When the temperature is low, the fan speed varies among high air flow, low air flow and breeze.

Q16 Loud noise from the outdoor unit is heard when operation is started.



A16 When operation is started, the compressor rotation speed goes to maximum to increase the heating or cooling capability, so noise becomes slightly louder. This does not indicate a fault.

Q17 Noise from the outdoor unit occasionally changes.



A17 The compressor rotation speed changes according to the difference between the thermostat set temperature and room temperature. This does not indicate a fault.

Q18 There is a difference between the set temperature and room temperature.



A18 There may be a difference between the set temperature and room temperature because of construction of room, air current, etc. Set the temperature at a comfortable for the space.

Q19 Air does not flow immediately after operation is started.



A19 Preliminary operation is performed for one minute when the power switch on and heating or dehumidifying is set. The operation lamp blinks during this time for heating. This does not indicate a fault.


TROUBLE SHOOTING

Model RAK-25NH4 / RAC-25NH4
 RAK-35NH4 / RAC-35NH4
 RAK-50NH4 / RAC-50NH4

PRECAUTIONS FOR CHECKING




- Remember that the 0V line is biased to 155-170V in reference to the ground level.
- Also note that it takes about 10 minutes until the voltage fall after the power switch is turned off.



Across (a) – (b) (0V line)..... approx 260-360V
 Across (a) – ground..... approx 155-170V
 Across (b) (0V line)– ground..... approx 155-170V



When using an oscilloscope, never ground it. Don't forget that high voltages as noted above may apply to the oscilloscope.



DISCHARGE PROCEDURE AND POWER SHUT OFF METHOD FOR POWER CIRCUIT




WARNING

Caution

- Voltage of about 300-330V is charged between both ends of smoothing capacitors
- During continuity check for each part of circuit in indoor unit electrical parts, disconnect red/gray lead wire connected from diode stack to system power module (SPM2) to prevent secondary trouble. (Be sure to discharge smoothing capacitor)

1. Turn OFF the Power supply to the outdoor unit.
2. After power is turned off, wait for 10 minutes or more. Then, remove electrical parts cover and apply soldering iron of 30 to 75W for 15 seconds or more to P2 and N1 terminals on system power module, in order to discharge voltage in smoothing capacitor.
3. Remove receptacle of red/gray lead wire connected to system power module from diode stack before performing operation check of each circuit.




System power module


Do not use a soldering iron with transformer: If one is used, thermal fuse inside transformer will be blown

As shown above, apply soldering iron to metal parts (receptacle) inside the sleeve corresponding to P1 and N1 terminals of system power module: Do this with smoothing capacitors kept connected. By removing red/gray lead wire from diode stack, power supply can be shut off. (corresponding to ⊕ and ⊖ terminals of system power module)

RAC-25NH4, RAC-35NH4




RAC-50NH4



CHECKING THE INDOOR/OUTDOOR UNIT ELECTRICAL PARTS AND REFRIGERATING CYCLE

Model RAK-25NH4 / RAC-25NH4
 RAK-35NH4 / RAC-35NH4
 RAK-50NH4 / RAC-50NH4









TROUBLESHOOTING WHEN TIMER LAMP BLINKS.


Model RAK-25NH4, RAK-35NH4, RAK-50NH4

Perform troubleshooting according to the number of times the indoor timer lamp and outdoor LD301 blink.

SELF-DIAGNOSIS LIGHTING MODE

Model: RAK-25NH4, RAK-35NH4, RAK-50NH4

No.	Blinking of Timer lamp	Reason for indication	Possible cause
1	 1 time	<u>Reversing valve defective</u> When the indoor heat exchanger temperature is too low in the heating mode or it is too high in the cooling mode.	(1) Reversing valve defective (2) Heat exchanger thermistor disconnected (only in the heating mode) (Note) The malfunction mode is entered the 3rd time this abnormal indication appears (read every 3 minutes).
2	 2 time	<u>Outdoor unit forced operation</u> When the outdoor unit is in forced operation or balancing operation after forced operation	Electrical parts in the outdoor unit
3	 3 times	<u>Indoor/outdoor interface defective</u> When the interface signal from the outdoor unit is interrupted.	(1) Indoor interface circuit (2) Outdoor interface circuit
4	 -- 9 times	<u>Room thermistor or heat exchanger thermistor is faulty</u> When room thermistor or heat exchanger thermistor is opened circuit or short circuit.	(1) Room thermistor (2) Heat exchanger thermistor
5	 -- 10 times	<u>Over-current detection at the DC fan motor</u> when over-current is detected at the DC fan motor of the indoor unit.	(1) Indoor fan locked (2) Indoor fan motor (3) Indoor control P.W.B.
※1 6	 -- 13 times	<u>IC401 or IC402 data reading error</u> When data read from IC401 or IC402 is incorrect.	IC401 or IC402 abnormal


( -- Lights for 0.5 sec. at interval of 0.5 sec.)

<Cautions>

- (1) If the interface circuit is faulty when power is supplied, the self-diagnosis display will not be displayed.
- (2) If the indoor unit does not operate at all, check to see if the F-cable is connected or disconnected.
- (3) To check operation again when the timer lamp is blinking, you can use the remote control for operation (except for mode mark ※1).

SELF-DIAGNOSIS LIGHTING MODE


MODEL: RAC-25NH4, RAC-35NH4 & RAC-50NH4





DANGER (DC360V)

- SWITCH OFF MAIN POWER SUPPLY TO THE OUTDOOR UNIT AT LEAST 10 MINUTES BEFORE START THE SERVICING WORK.
- MAKE SURE THE DC VOLTAGE LEVEL AT MEASURING POSITION (P1) AND (N1) IS LESS THAN 10V.
- DO NOT TOUCH THE SCREWS OF THE SYSTEM POWER MODULE WHEN THE UNIT IS TURNED ON. HIGH VOLTAGE STILL REMAIN EVEN AFTER THE UNIT IS TURNED OFF.
- DO NOT TOUCH ANY OTHER PARTS EXCEPT THE SERVICE SWITCH WHEN SERVICE OPERATION IS CONDUCTED.

SELF-DIAGNOSIS LIGHTING MODE		LD303 GOES OFF. <input type="checkbox"/>	
		[2] DURING STOP	
<input type="checkbox"/>	<input type="checkbox"/>	NORMAL STOP	INDOOR THERMOSTAT OFF. MAIN OPERATION OFF.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	RESET STOP	WHEN STOPPED WITH POWER RESET. (NORMAL WHEN POWER HAS BEEN TURNED ON).
<input checked="" type="checkbox"/>	<input type="checkbox"/>	PEAK CURRENT CUT	OVER CURRENT IS DETECTED.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	ABNORMAL LOW SPEED ROTATION	POSITION DETECTION SIGNAL IS NOT INPUT DURING OPERATION.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	SWITCHING FAILURE	FAIL TO SWITCH FROM INITIAL LOW FREQUENCY SYNC. TO POSITION DETECTION SYNC. .
<input checked="" type="checkbox"/>	<input type="checkbox"/>	OVERLOAD LOWER LIMIT CUT	OVERLOAD CONDITION STILL PERSISTING EVEN WHEN ROTATION SPEED IS BELOW THE LOWER RPM LIMIT.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	OH THERMISTOR	OH THERMISTOR IS OPERATING.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	TEMP. RISE	TEMP. RISE
<input checked="" type="checkbox"/>	<input type="checkbox"/>	ABNORMAL THERMISTOR	THERMISTOR IS OPENED OR SHORTED.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	ACCELERATION DEFECTIVE	NO ACCELERATION ABOVE THE LOWER LIMIT OF THE ROTATION SPEED.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	COMMUNICATION ERROR	COMMUNICATION BETWEEN INDOOR UNIT AND OUTDOOR UNIT ARE INTERRUPTED.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	POWER SUPPLY VOLTAGE ERROR	POWER SUPPLY VOLTAGE IS INCORRECT.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	FAN LOCK ERROR	OUTDOOR FAN RPM IS NOT ROTATE AS INTENDED RPM.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	EEPROM READING ERROR	MICROCOMPUTER CANNOT READ THE DATA IN EEPROM.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	ACTIVE CONVERTER DEFECTIVE	OVER VOLTAGE IS DETECTED BY SYSTEM POWER MODULE.

SELF-DIAGNOSIS LIGHTING MODE		LD303 LIGHTS. <input checked="" type="checkbox"/>	
		[1] DURING OPERATION	
<input type="checkbox"/>	<input type="checkbox"/>	NORMAL OPERATION	COMPRESSOR OPERATION
<input checked="" type="checkbox"/>	<input type="checkbox"/>	OVERLOAD (1)	 <p>THIS SHOWS AN OVERLOAD, NOT MALFUNCTION.</p>
<input type="checkbox"/>	<input checked="" type="checkbox"/>	OVERLOAD (2)	
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	OVERLOAD (3)	

* EXAMPLE OF BLINKING (5 TIMES)  2SEC  •• LIGHTS FOR 0.25 SEC. AT INTERVAL OF 0.25 SEC.)



WIRING DIAGRAM

BLK : BLACK GRY : GRAY
 BLU : BLUE RED : RED
 BRN : BROWN WHT : WHITE
 GRN : GREEN YEL : YELLOW

SERVICE OPERATION


COLLECT REFRIGERANT FROM INDOOR UNIT AND STORE AT OUTDOOR UNIT.

1. SWITCH OFF THE MAIN POWER SUPPLY AND THEN SWITCH IT ON AGAIN. WAIT FOR 1 MINUTE.
2. PRESS AND HOLD THE SERVICE SWITCH FOR 1 SECOND TO START OUTDOOR UNIT IN COOLING OPERATION. IN ORDER TO PREVENT PARTS FROM DAMAGE, DO NOT OPERATE THE OUTDOOR UNIT FOR MORE THAN 5 MINUTES.
3. PRESS AND HOLD THE SERVICE SWITCH FOR 1 SECOND TO STOP THE SERVICE OPERATION.
4. REPEAT STEP 1 TO 3 IF SERVICE OPERATION NEED TO BE REPEATED.




CHECKING INDOOR UNIT ELECTRICAL PARTS


1. Power does not come on (no operation)




2. Outdoor unit does not operate (but receives remote infrared signal)




3. Only indoor fan does not operate (other is normal)




4. Air deflector does not move (others are normal)




5. All systems stop from several seconds to several minutes after operation is started (all indicators are also off)



6. Check the main P.W.B (power circuit)




CHECKING THE REMOTE CONTROLLER



You can check the remote control switch by other methods as explained below.


Using the test card





The sensible area should flash in orange when you operate the remote control unit if it is good.


CHECKING THE OUTDOOR UNIT ELECTRICAL PARTS


MODEL RAC-25NH4, RAC-35NH4, RAC-50NH4












POWER CIRCUIT

Phenomenon 1 <Rotation speed does not increase>




Overvoltage defect: system power module faulty (15-times blinking)

CHECKING THE REFRIGERATING CYCLE

(JUDGING BETWEEN GAS LEAKAGE AND COMPRESSOR DEFECTIVE)

1. Troubleshooting procedure (No operation, No heating, No cooling)

Connect U,V,W phase leads to the power module again and operate the air conditioner.




Is the self-diagnosis lamp mode as shown on the right?

Lighting mode Self-diagnosis lamp	Blinks 2 times	Blinks 3 times	Blinks 4 times	Blinks 5 times	Blinks 6 times	Blinks 8 times
LD301						
Time until the lamp lights	Approx. 10 seconds			Approx. 10 seconds	Within Approx. 30 seconds	Approx. 10 seconds
Possible malfunctioning part	Compressor				Gas leakage	Compressor


Blinking off

YES




Stop to operate and check the gas pressure in balancing mode.

Normal
(0.39-0.98 MPaG)
(4-10 kg/cm²G)




● Checking the system power module

Gas leaking
(less than 4kg/cm²G)
(less than 0.39 MPaG)




Gas leaks.
Repair and seal refrigerant.

When the self-diagnosis lamp lights in the same condition as above.



The compressor is defective. Replace it and seal refrigerant.
(If the compressor checker for an inverter type air conditioner is available, re-check using it.)



Perform a final check of operation.

HOW TO CHECK SYSTEM POWER MODULE

Checking system power module using tester


Set tester to resistance range (X 100)

If indicator does not swing in the following conductivity check, the system power module is normal.

(In case of digital tester, since built-in battery is set in reverse direction, ⊕ and ⊖ terminals are reversed.)

⚠ CAUTION

If inner circuit of system power module is disconnected (open), the indicator of tester will not swing and this may assumed as normal. In this case, if indicator swings when ⊕ and ⊖ terminals are connected in reverse of diagram below, it is normal. Furthermore, compare how indicator swings at U, V and W phases. If indicator swings the same way at each point, it is normal.





HOW TO OPERATE USING THE SERVICE SWITCH THE OUTDOOR UNIT

MODEL RAC-25NH4, RAC-35NH4, RAC-50NH4

1. Turn off the power supply to outdoor unit and then turn on again.
2. Remove the electrical box cover.

LD303 (red) will light and the unit will operate in the forced cooling mode at this time.



(Cautions)

- (1) If interface signal (DC 35V) terminals C and D are not connected when the outdoor unit is in forced cool mode, the outdoor unit defect indicator (LD301) will blink 9 times during operation to indicate communication error.
- (2) If checking is done with the compressor connector disconnected, the unit will continue normal operation when the electrical parts are normal, or it will repeat operating for approx. one minute and stop due to overload power limit cut, or it will operate in the overload status.


Be sure to push the service switch again to stop the forced cool operation.

HOW TO OPERATE THE OUTDOOR UNIT INDEPENDENTLY

1. Connect the large dia. pipe side and small dia. pipe side service valves using a pipe.

Connect the small diameter service valve and the large diameter service valve using the reducing union and copper pipe as shown on the right.

Charge refrigerant of 300g after vacuuming (※ 1)



Parts to be prepared




- (1) Reducing union
2/8" (6.35mm)
1/2" (12.7mm)
- (2) Copper pipe (2/8" and 1/2")
- (3) Shorting leads
2 leads approx. 10 cm long with alligator clip or IC clip

Do not operate for more than 5 minutes

The operation method is the same as "How to operate using the connector to servicing the outdoor unit".

※ 1 The charging amount of 300g is equivalent to the load in normal operation.


SYSTEM POWER MODULE DIAGNOSIS

<p>Circuit diagram of the device (excepting the reflux diode)</p>	
<p>Circuit diagram of the module</p>	
<p>Terminals symbol mark of the module</p> <p>※ See next page for measuring value using tester</p>	

PARTS LIST AND DIAGRAM


INDOOR UNIT

MODEL : RAK-25NH4, RAK-35NH4, RAK-50NH4



**THE UPDATED PARTS LIST
FOR THIS MODEL IS
AVAILABLE ON ESTA**


OUTDOOR UNIT
MODEL : RAC-25NH4, RAC-35NH4



PARTS LIST AND DIAGRAM

OUTDOOR UNIT

MODEL : RAC-50NH4



**THE UPDATED PARTS LIST
FOR THIS MODEL IS
AVAILABLE ON ESTA**

HITACHI

Hitachi, Ltd. Tokyo, Japan
International Sales Division
THE HITACHI ATAGO BUILDING,
No. 15-12 Nishi Shinbashi, 2 - Chome,
Minato - Ku, Tokyo 105-8430, Japan.
Tel: 03 35022111

HITACHI EUROPE LTD,

Whitebrook Park
Lower Cookham Road
Maidenhead
Berkshire
SL6 8YA

UNITED KINGDOM

Tel: 01628 643000
Fax: 01628 643400
Email: consumer-service@hitachi-eu.com

HITACHI EUROPE S.A.

364 Kifissias Ave. & 1, Delfon Str.
152 33 Chalandri
Athens

GREECE

Tel: 1-6837200
Fax: 1-6835964
Email: service.hellas@hitachi-eu.com

HITACHI EUROPE GmbH

Munich Office
Dornacher Strasse 3
D-85622 Feldkirchen bei München

GERMANY

Tel: +49-89-991 80-0
Fax: +49-89-991 80-224
Hotline: +49-180-551 25 51 (12ct/min)
Email: HSE-DUS.service@hitachi-eu.com

HITACHI EUROPE S.A.

Gran Via Carlos III, 101-1
08028 Barcelona

SPAIN

Tel: 93 409 2550
Fax: 93 491 3513
Email: atencion.cliente@hitachi-eu.com

HITACHI EUROPE srl

Via Tommaso Gulli N.39, 20147
Milano, Italia

ITALY

Tel: +39 02 487861
Tel: +39 02 38073415 Servizio Clienti
Fax: +39 02 48786381/2
Email: customerservice.italy@hitachi-eu.com

HITACHI HOME ELECTRONICS (NORDIC) AB

Box 77 S-164 94 Kista

SWEDEN

Tel: +46 (0) 8 562 711 00
Fax: +46 (0) 8 562 711 13
Email: csgswe@hitachi-eu.com

HITACHI EUROPE S.A.S

Lyon Office
B.P. 45, 69671 BRON CEDEX

FRANCE

Tel: 04 72 14 29 70
Fax: 04 72 14 29 99
Email: france.consommateur@hitachi-eu.com

HITACHI EUROPE LTD (Norway) AB

STRANDVEIEN 18

1366 Lysaker

NORWAY

Tel: 67 5190 30
Fax: 67 5190 32
Email: csgnor@hitachi-eu.com

HITACH EUROPE AB

Egebækgård
Egebækvej 98
DK-2850 Nærum

DENMARK

Tel: +45 43 43 6050
Fax: +45 43 60 51
Email: csgnor@hitachi-eu.com

HITACHI EUROPE AB

Neopoli / Niemenkatu 73
FIN-15140 Lahti

FINLAND

Tel : +358 3 8858 271
Fax: +358 3 8858 272
Email: csgnor@hitachi-eu.com

Hitachi Europe Ltd

Bergensesteenweg 421
1600 Sint-Pieters-Leeuw

BELGIUM

Tel: +32 2 363 99 01
Fax: +32 2 363 99 00
Email: sofie.van.bom@hitachi-eu.com

HITACHI EUROPE LTD

Na Sychrove 975/8
101 27 Praha 10 - Bohdalec

CZECH REPUBLIC

Tel: +420 267 212 383
Fax: +420 267 212 385
Email: csgnor@hitachi-eu.com

www.hitachidigitalmedia.com